

Philips
Mini Hi-Fi System

FWM206



Enjoy MP3 music

with MP3 Link

Experience uninterrupted enjoyment of your CD/MP3/WMA songs for up to 10 hours on the FWM206. Extend your music pleasure by listening to your tunes at home from your portable player - with MP3 Link

Multiple source MP3 music

- Compatible with WMA and MP3 CDs
- MP3 Link for portable music playback

Enrich your sound experience

- 80W RMS total output power
- MAX Sound for instant power boost
- Digital Sound Control for optimized music style settings

Convenient and easy to use

- Clock, alarm and sleep timer
- Connection for TV or DVD player
- Digital tuning with preset stations for extra convenience

PHILIPS
sense and simplicity

Specifications

Sound

- Output power (RMS): 4x20W/ch
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control, MAX Sound
- Total Sound Power (RMS): 80 W

Loudspeakers

- Main Speaker: 4" woofer, 2" tweeter, 2 way, Bass Reflex Speaker System
- Number of Loudspeakers: 2

Audio Playback

- Number of Discs: 1
- Loader Type: Tray
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Repeat/one/disk/program, Shuffle Play, Fast Forward/Backward, Next/Previous Track Search, Repeat Play
- Programmable Tracks: 20

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm
- Clock: On main display
- Display Type: LCD

Connectivity

- Audio Connections: RCA Aux in, 3.5mm stereo line in -MP3 link

Accessories

- User Manual: Spanish, French, English
- Cables: MP3 Line-in cable
- Quick start guide: Spanish, French, English
- Remote control

Dimensions

- Set dimensions (W x H x D): 220 x 292 x 285 mm
- Speaker Width: 207 mm
- Speaker Height: 310 mm
- Speaker Depth: 186 mm
- Packaging dimensions (W x H x D): 730 x 348 x 275 mm
- Weight incl. Packaging: 10.38 kg

Power

- Power supply: 120V, 60Hz

Highlights

MAX Sound

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Optimal, Jazz, Techno and Rock controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



Issue date 2011-12-13

Version: 1.0.2

12 NC: 8670 000 55197
UPC: 6 09585 17522 8

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.