

Philips
CD Soundmachine with
Dynamic Bass Boost

MP3

AZ5130



MP3-CD Playback with Dynamic Bass Boost

CD Sound Machine with stereo sound through 2 big speakers. Power-packed sound machine with great stereo sound from MP3-CD, CD, cassette or radio.

Feature-packed VCD and CD player

- MP3-CD, CD-R/RW compatible

Rich and clear sound

- Dynamic Bass Boost for deep and dramatic sound
- Bass Reflex Speaker System delivers a powerful, deeper bass
- 10.2 cm (4") full range speakers for powerful sound

Easy to use

- CD to tape synchro-start recording
- Stereo headphone socket
- Handy remote control

PHILIPS

Specifications

Sound

- Loudspeaker types: Bass Reflex Speaker System
- Sound System: Stereo
- Speaker diameter: 4"
- Output power (RMS): 2X1.5W
- Volume Control: rotary

Loudspeakers

- Built-in speakers: 2
- Finishing: Metal
- Loudspeaker types: Loudspeakers

Video Playback

- Disc Playback Modes: A-B Repeat, Fast Backward, Fast Forward, Introscan, OSD, Pause, PBC, Slow Motion, Zoom

Audio Playback

- Cassette Deck Technology: Mechanical
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Number of decks: 1
- Programmable Tracks: 20

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording

Tuner/Reception/Transmission

- Antenna: AM Antenna, FM Antenna
- Auto digital tuning: No
- Tuner Bands: FM, MW

Connectivity

- Audio output: Stereo Audio (3.5 mm jack) 1x
- Video Output - Analog: Video (3.5mm jack) 1x

Convenience

- Display Digits: 3
- Display Type: LCD

Accessories

- Included accessories: AC Power Cord, Audio/Video cable, User Manual, Warranty certificate
- Remote control: 33 keys

Dimensions

- Packaging dimensions (W x H x D): 470 x 211 x 260 mm
- Product dimensions (W x H x D): 400 x 173 x 240 mm
- Weight: 3.5 kg
- Weight incl. Packaging: 4.2 kg

Power

- Battery type: LR14, UM2
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

Highlights

MP3-CD,CD-R/RW compatible

MP3-CD,CD-R/RW compatible

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

10.2 cm/4" full range speakers

10.2 cm (4") full range speakers for powerful sound

CD synchro-start recording

CD to tape synchro-start recording

Stereo headphone socket

Connect your own headphone for a more personal listening experience whenever you want it. You can enjoy your favorite music in great sound without disturbing others by connecting your headphones to the player.

Handy remote control

Handy remote control



Issue date 2014-02-05

Version: 6.0.7

12 NC: 9073 101 01323
EAN: 87 10895 82440 8

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com