

Philips
Micro Hi-Fi System

- Made for iPod
- MP3/WMA-CD playback

MCM398D



Enjoy your tunes in Hi-Fi sound quality

Play and charge your iPod

You're in touch with the latest and the coolest - Philips MCM398D lets you play your iPod music out loud with the docking cradle! Enjoy great sound in a compact form factor that fits in any room.

Play your iPod content out loud at home

- Play and charge your iPod simultaneously
- Single remote control for the system and iPod

Enrich your sound experience

- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x50W RMS and 2x100W music power

Start the day your way

- Wake up and sleep timer functions
- Digital tuning with 40 preset stations for extra convenience

Refined in sound and look

- Motorized CD loader for convenience access
- Elegant wood-finished speakers

PHILIPS

Highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses

graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of

the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Specifications

Sound

- Output Power: 2x50W RMS / 2x100W music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

Loudspeakers

- Main Speaker: 2 way, Bass Reflex Speaker System, 4" woofer, Piezo tweeter, Speaker grilles detachable

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- ID3-tag support
- Loader Type: Tray, Motorised
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop
- Cradle playback mode: Charging iPod, Fast forward and backward, Next and Previous track, Play and Pause

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- RDS: Station Name, Radio Text, RDS Clock Set
- Station presets: 40
- Tuner Enhancements: Auto Store

Connectivity

- Aux in: Line in
- Headphone: 3.5 mm

- Other connections: FM Antenna, Cradle connection
- USB: USB host

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm
- Clock: On main display
- Display Type: LCD
- Eco Power Standby: 1 watt

Accessories

- Included accessories: FM antenna
- Remote control: 24-key remote with Lithium battery
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- User Manual: 16 languages
- Cradle: Cradle and adaptors for iPod

Dimensions

- Set dimensions (W x H x D): 152 x 228 x 273 mm
- Main speaker dimensions (W x H x D): 140 x 228 x 244 mm
- Packaging dimensions (W x H x D): 514 x 275 x 345 mm
- Weight incl. Packaging: 8.7 kg

Power

- Power supply: 220-240V, 50Hz

iPod compatibility

- Compatible with: iPod, iPod mini, iPod nano, iPod shuffle, iPod with color display, iPod 5th Generation



Issue date 2013-05-10

Version: 1.0.10

12 NC: 8670 000 30869
EAN: 87 12581 34114 5

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com