



Philips
docking speaker

DS7620

Designed to go places

Obsessed with sound

Compact and extremely portable, this speaker is no lightweight when it comes to performance. Designed to travel it delivers sound from your iPod/iPhone that is surprisingly powerful - letting you enjoy great music wherever life takes you.

Sound that blows you away

- wOOx technology for rich yet precise bass without distortion
- DBB to preserve low tones for deep bass at any volume level
- Shielding technology to block mobile phone interference

Made to go places

- Elegant, slim and compact design to fit into any briefcase

Truly portable and versatile

- Crushproof and shockproof for safe transit
- Battery or AC power option for music enjoyment anywhere
- Dock any iPod/iPhone, even in its case
- AUX-in for easy connection to almost any electronic device
- Free DockStudio app for internet radio & other cool feature

PHILIPS

Specifications

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

iPod compatibility

- Compatible with: iPod, iPod mini, iPod with color display, iPod classic, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod touch, iPod nano 4th Generation, iPod touch 2nd Generation, iPod nano 5th Generation, iPod touch 2nd Gen 8/16/32GB, iPod 5th Generation, iPod nano, iPod nano 6th generation

iPod/iPhone App

- App name: DockStudio
- Free download from App store
- Compatibility: iPhone OS 3.0
- Playback: Album/track navigation, Playback controls
- Sound settings: DBB, DSC-Flat, Pop, Rock, Jazz, Classic
- Clock: Analog display, Digital display
- Alarm: Multiple alarms, Sleep timer, Wake up to music, Wake up to nature sounds, Wake up to photo
- Battery status: Speaker battery status
- 7000+ Internet radio stations
- Worldwide weather forecast

Connectivity

- Aux in

Audio Playback

- Cradle playback mode: Charging iPhone, Charging iPod

Sound

- Output power (RMS): 10W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Volume Control: Volume Control up/down

Loudspeakers

- Neodymium magnet system

Accessories

- Cables: 3.5mm AUX-in

Power

- Power supply: 100-240VAC, 50/60Hz, Battery
- Battery Type: Built-in battery
- Operating time on battery: 8 hr

Dimensions

- Master carton weight: 2.3 kg
- Product dimensions (WxDxH): 310 x 110 x 40
- Weight incl. Packaging: 1.04 kg
- Master carton dimensions: 175 x 162 x 440 mm
- Master carton quantity: 2
- Weight: 0.76 kg



Highlights

wOOx technology



wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

Dock iPod/iPhone in its case



Smartly designed spring-loaded docking port effortlessly accommodates any iPod or iPhone, without special adaptors. What's more, it works even when most protective cases are on – just dock your iPod or iPhone as it is. Now you can truly have fuss-free enjoyment of your music.

Crushproof and shockproof

This portable docking speaker is built for worry-free handling. Featuring state-of-the-art engineering, the docking station is innovatively constructed for the ultimate in shock-absorbency and structural rigidity. Built to withstand drops of up to two meters and the pressure of weights of up to 100 kg/220 pounds, the dock's unmatched ruggedness means you can truly bring it everywhere you go, knowing that it will emerge safely from transit.

DockStudio app on App Store



The free app adds an array of exclusive cool features to your docking speaker. You can check the weather, tell the time and even use your favorite images as wallpaper. DockStudio also lets you listen to thousands of Internet radio stations worldwide. More updates on skin styles and new functions on the way.



Issue date 2014-03-26

Version: 2.0.2

12 NC: 8670 000 75776
UPC: 6 09585 21393 7

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com