

Philips
DVD micro music system

• Dock for iPod/iPhone/iPad

DCD2030



Relax to great music and movie

Obsessed with sound

Get great movie & music experiences with this Philips DVD Micro system. Play and charge your iPod/iPhone/iPad, or enjoy DVDs, DivX, MP3-CDs and portable players via USB Direct and MP3 Link - all with the superb bass of Bass Reflex speakers.

Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Dolby Digital for ultimate movie experience
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 20W RMS total output power

Enjoy your music and movie from multiple sources

- Play and charge your iPod/iPhone/iPad
- Play DVD, DivX® Ultra, MP3/WMA-CD, CD and CD-RW
- USB Direct for music and photo playback
- MP3 Link for portable music playback

Easy to use

- Motorized CD loader for convenience access
- Digital tuning with preset stations for extra convenience

PHILIPS

Highlights

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Dolby Digital

Dolby Digital lets you experience superb quality surround sound audio with realistic spatial cues. You will get the same great Dolby Digital audio quality no matter what you are watching - a DVD or Blu-ray disc, TV or downloaded content. Best of all, you can be confident that you will hear the audio exactly as it was intended, because Dolby Digital is also used to create the soundtracks for movies and games. Dolby Digital delivers premium surround sound experiences in the cinema and your home.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls

you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Play & charge iPod/iPhone/iPad



Enjoy your favorite MP3 music while charging your iPod/iPhone/iPad! The dock lets you connect your portable device directly to the Philips system so you can listen to your favorite music in superb sound. It also charges your iPod/iPhone/iPad while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The

system automatically charges your portable device while it is docked.

USB Direct



Simply plug in your USB device on the system and share your stored digital music and photos with your family and friends.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.



Specifications

Sound

- Output power: 2 x 10 W RMS
- Sound enhancement: digital sound control, Dynamic Bass Boost
- Sound System: Dolby Digital

Loudspeakers

- Speaker drivers: 4" woofer
- Speaker types: bass reflex speaker system

Audio playback

- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive, WMA-CD
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat, shuffle, stop
- Docking playback modes: fast forward and backward, menu, up and down, next and previous track, play and pause
- Others: ID3-tag support

Video Playback

- Disc Playback Modes: A-B Repeat, Angle, Slow Motion, Zoom, Parental control, Disc Menu, Fast Backward, Fast Forward, OSD, Resume Playback from Stop, Pause, Repeat, Search forward/reverse, Skip, Standard Play
- Playback Media: Video CD/SVCD, DVD, DVD-Video, DVD+R/+RW, DVD-R/-RW, DivX Ultra, USB flash drive
- DVD Region Code: 3

Digital Photo Playback

- Picture Compression Format: JPEG
- Picture Enhancement: Rotate, Slideshow with MP3 playback, Zoom

Tuner/Reception/Transmission

- Tuner bands: FM mono, FM stereo
- Station presets: 20
- Antenna: FM antenna (75 ohm)
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug & play)

Connectivity

- Headphone: 3.5 mm
- MP3 Link: 3.5mm stereo line in
- Rear Connections: Composite video (CVBS) output, Digital coaxial out, AUX in, Line out, FM

- Antenna, Left and right speakers, Component Video output
- USB: USB host

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm, iPod Alarm
- Clock: On main display, sleep timer
- Display type: LCD display
- Loader type: tray
- On-Screen Display languages: Bahasa Indonesia, Simplified Chinese, Thai, Traditional Chinese
- Charging device: iPad, iPhone, iPod

Accessories

- Included accessories: Composite video cable (Y), AC Power Cord, FM antenna, Quick Use Guide
- Remote control: 34-key remote
- User Manual: English, Traditional Chinese

Dimensions

- Main unit width: 200 mm
- Main unit height: 118 mm
- Main unit depth: 210 mm
- Main speaker dimensions (W x D): 140 x 144 mm
- Main speaker height: 224 mm
- Packaging width: 576 mm
- Packaging height: 274 mm
- Packaging depth: 190 mm
- Gross weight: 3.9 kg
- Net weight: 3.34 kg

Power

- Power supply: 110-240V, 50/60 Hz

iPod compatibility

- Compatible with: iPod classic, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod nano 5th Generation, iPod nano 6th generation, iPod touch, iPod touch 2nd Generation, iPod touch 3rd generation, iPod touch 4th generation

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

iPad compatibility

- Compatible with: iPad, iPad 2



Issue date 2013-05-10

Version: 1.1.8

12 NC: 8670 000 78394
EAN: 87 12581 60848 4

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com