

Philips
Earhook Headphones

SBCHJ080



Innovation for athletes

Metal 3-way adjustable sport headphones

Lightweight just got tougher. A radical new design aimed at athletes and audiophiles, Skylon Flight all metal headphones are small, lightweight and three-way adjustable for a world of different size ears.

Innovation for Athletes

- A 1.2m long cable that is ideal for outdoor use
- 15mm speaker driver optimizes wearing comfort
- 3-way adjustment for personalized comfort and stability
- Carrying pouch protects your headphone when not in use
- Copper Cladded Aluminium Wire improves sound quality
- for excellent comfort and durability
- Lightweight design improves comfort for prolonged use.
- Neodymium magnet enhances bass performance and sensitivity
- Reinforced cable connection ensures extra durability
- for use in active sports

PHILIPS

Technical specifications

Sound

- **Acoustic system:** Open
- **Frequency response:** 8 - 24 000 Hz
- **Impedance:** 16 Ohm
- **Magnet type:** Neodymium
- **Maximum power input:** 50 mW
- **Sensitivity:** 104 dB
- **Speaker diameter:** 15 mm
- **Type:** Dynamic
- **Voice coil:** CCAW

Connectivity

- **Connector:** 3.5 mm stereo
- **Finishing of connector:** Chrome plated
- **Cable length:** 1.2 m
- **Type of cable:** OFC
- **Cable Connection:** Two-parallel, symmetric

Accessories

- Carrying case

Product highlights

1.2 meter cable

The ideal cable length to give you the freedom to put your audio device where you want.

15 mm speaker driver

Small enough for optimum wearing comfort and big enough to deliver crisp, non-distorted sound, the 15 mm speaker driver is an ideal size for listening enjoyment.

3-way adjustable

Enjoy a snug, personalized fit and optimum stability, even when you're active or on the move. With three-way adjustment, your comfort is guaranteed.

Carrying pouch included

Look after your headphone and stop the cable getting tangled by storing it in this handy soft pouch.

CCA W voice coil

By using top-quality Copper Cladded Aluminium Wire (CCA W) in the headphone driver's voice coil, the sound quality is considerably improved.

Durable all metal housing

Lightweight design

The durable, lightweight quality materials enhance comfort for extended wearing.

Neodymium magnet

Neodymium is the best material for producing a strong magnetic field for greater sensitivity in a voice coil, better bass response and higher overall sound quality.

Reinforced cable connection

A soft plastic part on the earshell reduces cable strain, protects the connection and prevents damage from repeated bending.

Sweat-resistant ear cushions



Date of issue 2006-07-07

Version: 4.0

12 NC: 9082 100 02539
EAN: 87 10895 80459 2

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
© 2006 Koninklijke Philips Electronics N.V.
All Rights reserved.
www.philips.com