



Philips Fidelio  
docking sound system

Bluetooth® aptX and AAC



DTM9030

## The towering art of wireless sound

### Obsessed with sound

Be immersed in high-fidelity sound with the Philips Fidelio sound towers. Stream music wirelessly with Bluetooth® aptX and AAC. Play your CDs or any iPod or iPhone with Philips DualDock. Get room-filling sound with only two speakers.

#### Enjoy freedom with Bluetooth® wireless technology

- Floor standing speakers for ideal music reproduction
- Playback music via Bluetooth® wireless technology and aptX®

#### Enjoy your music from multiple sources

- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for MP3/WMA music playback
- MP3 Link for portable music playback
- DualDock to charge & play iPod/iPhone (Lightning & 30pin)

#### Enrich your sound experience

- 160W RMS total output power

#### Design that blends into your interior

- Unique tower design to fit your lifestyle

**PHILIPS**  
Fidelio

# Highlights

## USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

## MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do

is to plug your portable MP3 player to the audio system.

## DualDock to charge & play



Created to meld sleek styling with Lightning and 30-pin Apple device connectivity, the DualDock pops out when needed to reveal connectors and act as an iPhone/iPod stand.

## Floor standing speakers



Fidelio Sound Towers are floor standing speakers that offer the optimum amount of acoustic volume for the creation of a rich and

pristine sound. They combine the mid-range accuracy of a traditional 2-way speaker design with bass extensions to support the low end of the sonic spectrum, making them ideally tuned for exquisite music reproduction.

## Play MP3/WMA-CD, CD and CD-RW



Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player. Download MP3 or WMA songs from authorized music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.

## Playback music via Bluetooth

Playback mobile phone and PC music via Bluetooth® wireless technology and aptX®



# Specifications

## iPod compatibility

- Compatible with: iPod nano 7th generation, iPod touch 5th generation, iPod classic, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod nano 5th generation, iPod nano 6th generation, iPod touch, iPod touch 2nd generation, iPod touch 3rd generation, iPod touch 4th generation
- via Bluetooth: iPod nano 7th generation, iPod touch 3rd generation, iPod touch 4th generation, iPod touch 5th generation
- via Lightning connector: iPod nano 7th generation, iPod touch 5th generation

## iPhone compatibility

- via 30-pin connector: iPhone 3G, iPhone 3GS, iPhone 4, iPhone 4S
- via Bluetooth: iPhone 3G, iPhone 3GS, iPhone 4, iPhone 4S, iPhone 5, iPhone 6, iPhone 6 Plus, iPhone 6S, iPhone 6S plus, iPhone SE
- via Lightning connector: iPhone 5, iPhone 6, iPhone 6 Plus, iPhone 6S, iPhone 6S Plus, iPhone SE

## Sound

- Output power (RMS): 2 x 80W (<1% THD)
- Sound enhancement: digital sound control 4 modes
- Volume control: up/down

## Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 4" woofer
- No. of built-in speakers: 6

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD, USB flash drive
- Disc Playback Modes: Repeat/one/all/program, Shuffle Play, 20-Track Programmable, Fast Forward/Backward, Next/Previous Track Search
- Loader Type: Motorised
- ID3-tag support
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop
- Cradle playback mode: Charging iPhone, Charging iPod

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- RDS: Program Type, Station Name, RDS Clock Set
- Station presets: 20
- Antenna: FM antenna
- Tuner Enhancements: Auto Store

## Connectivity

- Other connections: FM Antenna
- 3.5mm stereo line in: MP3 Link
- Rear Connections: AUX in, Digital coaxial in, Digital optical in
- Bluetooth profiles: A2DP, AVRCP, aptX

## Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm, iPod Alarm
- Clock: On main display, sleep timer
- Display Type: VFD display
- Eco Power Standby: 0.5 watt
- Charging device: iPhone, iPod
- Display type: VFD display

## Accessories

- Included accessories: AC Power Cord, FM antenna, Audio Cable
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- Remote control
- User Manual: 16 languages

## Dimensions

- Packaging dimensions (W x H x D): 560 x 1120 x 390 mm
- Gross weight: 30.7 kg
- Net weight: 26.3 kg
- Main unit depth: 300 mm
- Main unit height: 985 mm
- Main unit width: 300 mm

## Power

- Power supply: 220-240V, 50Hz

## iPad compatibility

- via Bluetooth: iPad Air 2, iPad mini 2, iPad mini 4, iPad Pro



Issue date 2016-06-28

Version: 4.1.6

12 NC: 8670 001 06009  
EAN: 87 12581 69620 7

© 2016 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)