

Philips
DVD Micro Theatre

- DivX playback
- USB Direct



MCD716

Excellent movie and sound experience

plus USB Direct playback

A high-quality component system that boasts a stylish and stunning design. The black higloss speakers deliver high-quality sound, and with DVD playability you can now satisfy both your audio and video needs on one micro system.

Enrich your movie experience

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) and Picture CD
- 12-bit/108 MHz video processing for sharp and natural images
- Dolby Digital for ultimate movie experience

Enrich your sound experience

- Neodymium Ribbon Tweeter for impressive audio fidelity
- · Class 'D' digital amplifier for quality sound performance
- USB Direct for music and photo playback
- Dynamic Bass Boost for deep and dramatic sound
- 100 W RMS total output power

Design that blends into your interior

- Black high-gloss speakers for premium look and feel
- · High-end component design with stand
- · Aluminium cabinet for quality look and feel



Highlights

12-bit/108 MHz video processing

12-bit Video DAC is a superior Digital-to-Analogue Converter that preserves every detail of the authentic picture quality. It shows subtle shades and smoother graduation of colours, resulting in a more vibrant and natural picture. The limitations of the standard 10-bit DAC become particularly apparent when it is used with large screens and projectors.

Dolby Digital

Because Dolby Digital standards, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.

Neodymium Ribbon Tweeter

The Neodymium Ribbon Tweeter is a monopole tweeter that produces dynamic and crisp sound from the front. It is a feature commonly used in high-end audio systems to reproduce sound with excellent fidelity. Conventional cones and dome tweeters are based on a directional moving coil principle,

whereas the monopole Neodymium Ribbon Tweeter radiates high frequencies in a full 180-degree radiation pattern. This dramatically increases the width of the sound spectrum in the higher tones and expands the sweet spot zone to deliver wide, crystal-clear and natural sound, even from compact audio systems.

Class 'D' Amplifier

The Class 'D' Digital Amplifier takes an analogue signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, the Class 'D' Digital Amplifier has over 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

USB Direct

Simply plug your USB device into the system and share your stored digital music and photos with your family and friends.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high — at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

High-end component design

The component-designed micro system comes with a stand that features four triangular feet. It can prevent any audio frequency distortion due to vibration, overheating and electromagnetic interference generated from the amplifier and CD loader. The result is smooth and excellent sound reproduction.













Specifications

Sound

- Output Power: 2 x 50 W RMS/2 x 100 W music power
- Sound Enhancement: Class "D" Digital Amplifier, Digital Sound Control 4 modes, Dynamic Bass Boost, Loudness
- Sound System: Dolby Digital

Loudspeakers

 Main Speaker: 2-way, Bass Reflex Speaker System, Speaker grilles detachable, 5" woofer, Ribbon tweeter

Video Playback

- Playback Media: DivX, DVD-Video, Picture CD, Video CD/SVCD, DVD+R/+RW, DVD-R/-RW
- Disc Playback Modes: A-B Repeat, Angle, PBC, Zoom, Parental control, Disc Menu, Fast Reverse, Fast Forward, OSD, Resume Playback from Stop, Slow Motion
- DVD Region.: 2

Still Picture Playback

- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow with MP3 playback
- Playback Media: Picture CD, CD-R/RW, DVD+R/ +RW

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Shuffle Play
- · Loader Type: Motorised, Tray
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- · Auto digital tuning
- Station presets: 20

- RDS: Programme Type, Radio Text, RDS Clock Set, Station Name
- Tuner Enhancements: Auto Store

Connectivity

- Video Output Analogue: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden), SCART
- Other connections: Digital audio coaxial out, FM Antenna
- USB: USB host
- · Headphones: 3.5 mm
- Audio Connections: Analogue Audio In (L/R), Analogue Audio Out (L/R)

Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm, USB alarm
- · Clock: On main display
- OSD Languages: English, Dutch, French, German, Italian, Portuguese, Spanish, Swedish, Turkish
- Display Type: VFD display
- Indications: DIM mode
- Eco Power Standby: 1 watt

Accessories

- Included accessories: Composite video cable (Y), Control cable, AC Power Cord, FM antenna, World Wide Warranty leaflet
- Remote control: 47-key with $2 \times AAA$ batteries
- User Manual: English
- · Quick start guide: English

Dimensions

- Set dimensions (W x H x D): 240 x 160 x 230 mm
- Main speaker dimensions (W x H x D): 160 x 270 x 220 mm
- Weight incl. Packaging: 12.5 kg
- Packaging dimensions (W x H x D): 525 x 375 x 330 mm

Power

• Power supply: 220-240 V, 50 Hz



Issue date 2013-05-10

Version: 1.0.5

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 39589 EAN: 87 12581 42142 7

www.philips.com