



Philips
Uninterruptible power
supply

Battery back-up

10 outlets

SPB8868WA

33 min. runtime

Back up your computer system

This powerful battery back-up offers a compact and lightweight design to easily fit anywhere.

Ideal for computer workstations

- Data line/phone protection
- Phone/data jack
- 6 ft USB cable
- Phone cord

Ultimate performance design

- 850VA, 425W
- Automatic Voltage Regulator (AVR)
- Auto shutdown software
- \$250,000 connected equipment warranty

Built-in convenience

- 6 ft power cord
- Audible alarm
- LED indicators for information at a glance

PHILIPS
sense and simplicity

Uninterruptible power supply
Battery back-up 10 outlets

Specifications

Packaging

- Quantity: 1
- Gross Weight: 6.123 kg
- Tare Weight: .431 kg
- Net Weight: 5.692 kg
- Length: 50.8 cm
- Width: 17.1 cm
- Height: 18.4 cm

Outer Carton

- EAN/UPC/GTIN: 1 06 09585 13232 7
- Quantity: 2
- Gross Weight: 12.383 kg
- Tare Weight: .227 kg
- Net Weight: 12.156 kg
- Length (cm): 38.1 cm
- Width (cm): 18.4 cm
- Height (cm): 52.6 cm

SPB8868WA/17

Highlights

Data line/phone protection

These connectors accommodate either an RJ45 or an RJ11 cord. They route either line through the surge protector to guard against spikes and surges that may occur in the data or phone lines.

850VA, 425W

This power rating advises how much total power you are able to back up without overloading the battery.

AVR

Provides consistently clean power. Adjusts power to the nominal level if the input power is a too high or low.

Auto shutdown software

Ensures that all open files are saved and computer shuts down safely without completely draining the battery

Phone/data jack

MOVs or sidactor are used for protecting the phone or network lines. They protect against surges/spikes through the phone or network lines.

\$250,000 equipment warranty

Protects your connected equipment for the life of the product.

6 ft power cord

Provides power to the unit which can be 6 feet from the AC outlet.

6 ft USB cable

Connects computer to UPS so that power monitor and auto shutdown can be executed.

LED indicators

These LED indicators inform you of unit status at a glance

Phone cord

Allows you to connect a phone or fax machine



Issue date 2009-11-06

Version: 3.0.7

12 NC: 8670 000 29647
UPC: 6 09585 13232 0

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com