



Philips  
Webcam

VGA  
CMOS

SPC525NC



## Keep in contact the easy way

Now you can see and hear your loved ones wherever they are in the world. This wonderfully straightforward webcam takes great video and also includes a multimedia headset for equally good sound. Keep in contact the easy way.

### Natural video at higher resolutions

- 1.3 Mega pixels for extra image quality
- Smooth image with 30 frames per second video
- Face tracking automatically follows your face
- 3X digital zoom
- Turn the camera 360° on its pivot joint

### Clear and natural voice

- Built-in digital microphone for quality sound
- Multimedia headset and head mic for best sound quality

### Perfectly user-friendly

- Installation manager for easy set-up
- Compatible with all instant messaging services
- Snapshot button lets you take great instant photos
- Stable mount on any monitor laptop or desk
- Take, archive and manage images with VLounge

# PHILIPS

# Specifications

## Video & snapshot capturing

- Sensor: CMOS
- Sensor resolution: VGA
- Video resolution: 1.3 MP
- Snapshot resolution: VGA
- Interpolated snapshot res.: 1.3 MP
- Max. frame rate: 30 fps
- Lens: F2.6, D50°
- White balance: 2600 – 7600 K
- Color depth: 24 bit

## Mechanics

- Laptop clamp
- LCD clamp
- CRT stand
- Desktop stand
- Digital built-in microphone
- Snapshot button

## Accessories

- Included accessories: User Manual, Multimedia headset SHM2000, Quick install guide

## Software

- VLounge: Premium
- Add video to: Yahoo! Messenger, AOL Messenger, Skype, ICQ, QQ, Windows Live Messenger, MSN Messenger

## System Requirements

- Operating System: Microsoft Windows XP, Microsoft Windows Vista Home, Microsoft Windows Vista
- Processor: Pentium III 500MHz or faster

- RAM memory: 128 MB RAM
- Sound card
- USB: Free USB port
- Internet connection
- Hard disk space: 200 MB
- CD-ROM or DVD-ROM Drive

## Connectivity

- Cable length: 1.5
- PC Link: USB 2.0

## Dimensions

- Product dimensions (W x H x D): 35 x 125 x 75 mm
- Product weight (g): 79

## Packaging Data

- 12NC: 908210008694
- EAN/UPC/GTIN: 87 10895 97761 6
- Quantity: 1
- Height: 186 mm
- Length: 230 mm
- Width: 92 mm
- Gross weight: 0.418 kg
- Tare weight: 0.339 kg

## Outer Carton

- EAN/UPC/GTIN: 87 12581 33419 2
- Quantity: 6
- Height: 260 mm
- Length: 392 mm
- Width: 292 mm
- Gross weight: 3.2 kg
- Tare weight: 3.126 kg

# Highlights

## 1.3 Mega pixels

With 1.3 Mega pixels you can use your webcam as a camera for taking high-quality photographs that are even good enough for printing larger sized high quality images.

## 30 frames per second video

Sit back and enjoy superior viewing with 30 frames per second video. This gives you smoother video images and a better all-round video-chatting experience.

## Automatic face tracking

The state-of-the-art camera software automatically detects your face and moves the lens to follow you as you move. You stay in the center of the image even if you move during a video conference. It gives you the freedom to express yourself and converse naturally.

## 3X digital zoom

This built-in digital zoom lens allows you to easily shoot from a distance, bringing subjects closer.

## Pivot joint

Enjoy easy webcamming freedom with this handy pivot joint design. Just twist the camera 360° in any direction to film anywhere in your room without moving the webcam at all.

## Built-in digital microphone

The built-in digital microphone allows you to talk naturally and freely or to add sound to a video clip recording.

## Multimedia headset included

Included with your webcam is a Philips multimedia headset. The head mic ensures optimum sound quality and comfortable use.

## Compatible with all services

The webcam and its software have been designed with all instant messaging services in mind. Add video to Skype, Windows Live Messenger, Yahoo! Messenger, AOL Instant Messenger and other services.

## Snapshot button

With just one press of this button, your webcam takes a picture automatically. It's a fun way to share your pictures by adding them to e-mails, web pages or documents.

## Stable mount

The multifunctional stand makes it easy for you to mount the webcam on any monitor, laptop, notebook or flat surface.

## VLounge software

Software for capturing, managing and archiving snapshots and video clips in a very convenient way. With just a couple of mouse clicks you will be able to create and send Video mails. This software package gives you all you need to take full advantage of your Philips webcam.



Issue date 2017-07-26

Version: 4.1.11

12 NC: 9082 100 08694  
EAN: 87 10895 97761 6

© 2017 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)