



Philips
Wireless hi-fi headphones

FM transmission

Rechargeable

SBCHC8440



Wireless music

Rechargeable

Just imagine it, no hassles with cables, and the freedom to move around and enjoy your music with a quality FM wireless stereo headphone.

You'll forget you're wearing them!

- 3-way adjustment for a better fit and bass performance
- Lightweight design improves comfort for prolonged use.

The perfect wireless listening experience

- ALC helps prevent audible distortion of input signals
- 32mm speaker driver delivers high performance sound

Always ready to go

- FM Wireless transmission for freedom of movement
- Choose from 2 channels to minimize interference
- Reduces costs by using rechargeable batteries

PHILIPS

sense and simplicity

Specifications

Sound

- Acoustic system: closed
- Frequency response: 10 - 22 000 Hz
- Magnet type: Neodymium
- Sensitivity: 100 dB
- Speaker diameter: 32 mm

Tuner/Reception/Transmission

- Channel separation: >30 dB
- Pilot tone frequency: 19
- Effective range: 100 m
- Carrier frequency range: 863.0 - 865.0 MHz
- Modulation: FM
- Number of channel: 2

Convenience

- Battery charging indicator
- Low battery indicator
- Double PLL
- Operating time: +/- 15 hours
- Automatic power off



Power

- Power supply headphone: 2 x 1.5 V NiMH R03/AAA
- Power supply transmitter: AC/DC adapter 12V/200mA

Outer Carton

- EAN: 87 10895 82215 2
- Number of consumer packagings: 6
- Gross weight: 5.12 kg
- Outer carton (L x W x H): 45.2 x 33.5 x 33.2 cm
- Nett weight: 3.69 kg
- Tare weight: 1.43 kg

Packaging dimensions

- EAN: 87 10895 80706 7
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 10.5 x 21.4 x 28.3 cm
- Gross weight: 0.848 kg
- Nett weight: 0.615 kg
- Tare weight: 0.233 kg

Highlights

3-way adjustable ear shells

Enjoy a comfortable fit and experience better bass performance thanks to the three-way adjustable ear shells that fit naturally around your ears.

Lightweight design

The durable, lightweight quality materials of these Philips headphones enhance comfort for extended wearing.

Automatic Level Control (ALC)

This smart electronic circuit ensures that the audio input level is automatically adjusted to the right level, preventing distortion and preserving your listening enjoyment.

32 mm speaker driver

The 32 mm speaker driver is a compact yet powerful element for delivering non-distorted sound with any given input power.

FM Wireless transmission

With high frequency FM wireless transmission, which can even pass through walls, you can even listen to your music when you're in another room.

2 transmission channels

With a choice of two transmission channels your listening pleasure is protected because you can easily switch to the one with the best reception.

Rechargeable system

The headphone set incorporates facilities for recharging the batteries.

