

Philips
CD Soundmachine

DVD

AZ5737



Enjoy your favorite DVD movies, photos and music

You can now enjoy your favorite movies, music and even photos on the TV with this all-in-one DVD Soundmachine. Powerful stereo music and sound effects are delivered through two full range Bass Reflex speakers 10.2 cm (4").

Everything you need

- Play DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD
- FM/MW tuner for radio enjoyment
- Autostop cassette deck

Rich and clear sound

- 10.2 cm (4") full range speakers for powerful sound
- Bass Reflex Speaker System delivers a powerful, deeper bass

Easy to use

- CD to tape synchro-start recording
- Multi-functional LCD display
- On Screen Display for easy navigation
- Convenient remote control

PHILIPS

Specifications

Video Playback

- Playback Media: DVD-Video, DVD+R/+RW, Picture CD, Video CD/SVCD
- Disc Playback Modes: A-B Repeat, Fast Backward, Fast Forward, OSD, Pause, PBC, Zoom

Audio Playback

- Cassette Deck Technology: Mechanical
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Number of decks: 1
- Programmable Tracks: 20

Tuner/Reception/Transmission

- Antenna: FM Antenna
- Tuner Bands: FM, MW

Sound

- Output power (RMS): 2x1W
- Sound System: Stereo
- Speaker diameter: 4"
- Volume Control: rotary

Loudspeakers

- Built-in speakers: 2
- Finishing: Metal

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording

Connectivity

- Audio output: Stereo Audio (3.5 mm jack) 1x
- Video Output - Analog: Video (3.5mm jack) 1x

Convenience

- Display Type: LCD
- Display Digits: 7
- Remote control

Accessories

- Remote control: 33 keys
- Included accessories: AC Power Cord, Audio/Video cable, User Manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D): 458 x 210 x 280 mm
- Product dimensions (W x H x D): 400 x 169 x 242.5 mm
- Weight: 3.2 kg
- Weight incl. Packaging: 4.13 kg

Power

- Mains power: AC 100 - 240 V, 50/60 Hz

Highlights

10.2 cm/4" full range speakers

10.2 cm (4") full range speakers for powerful sound

CD synchro-start recording

CD to tape synchro-start recording

Multi-functional LCD display

Multi-functional LCD display

On Screen Display

On Screen Display for easy navigation

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.



Issue date 2014-02-10

Version: 1.0.3

12 NC: 8670 000 33395
EAN: 87 12581 36010 8

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com