

# PHILIPS

Portable MP3-CD  
Player

MP3-CD playback

EXP2545



## Enjoy skip-free MP3 music

Get into your groove with the eXp2545 MP3-CD players and enjoy 7.5 hours of skip-free music on one MP3-CD. A classic favourite, it comes with LCD display and is a great choice for easy and hassle-free music enjoyment on the go

### **Jogproof**

- 100-second Magic ESP™

### **Play your CDs and MP3-CDs**

- Play CD, CD-R and CD-RW discs
- Enjoy 7.5 hours of music on one MP3-CD

### **Enhanced bass performance**

- Dynamic Bass Boost for deep and dramatic sound

# Highlights

## Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume



settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Sound

**D/A converter:** 1-bit  
**Frequency response:** 20 - 20 000 Hz  
**Output Power:** 2 x 4mW RMS  
**Sound Enhancement:** Dynamic Bass Boost  
**Signal to noise ratio:** > 85dB  
**Volume Control:** digital

## Connectivity

**DC in:** 4.0 mm, 4.5V, centre +  
**Headphone:** 3.5 mm

## Convenience

**Display Type:** LCD  
**Indications:** album number, battery status, Cd functions, DBB, ESP, time, track

## Accessories

**Headphones**  
**Included accessories:** User Manual

## Dimensions

**Master carton quantity:** 5  
**Packaging Depth:** 45 mm  
**Product dimensions (WxDxH):**  
 140x140x27.5mm  
**Packaging Height:** 272 mm  
**Packaging type:** Clamshell  
**Packaging Width:** 196 mm  
**Master carton depth:** 260 mm  
**Master carton weight:** 2.39 kg  
**Master carton height:** 244 mm  
**Master carton width:** 305 mm  
**Product weight:** 0.38 kg

## Audio Playback

**Disc Playback Modes:** Hold, Next/Previous Album Search, Next/Previous Track Search, Repeat Play, Shuffle Play  
**Playback Media:** MP3-CD, CD, CD-R, CD-RW  
**MP3 bit rates:** 32 - 320 kbps  
**Electronic Skip Protection(CD):** 45 seconds  
**File systems supported:** ISO-9660, Joliet  
**Magic ESP (MP3-CD):** 100 seconds

## Battery

**Type:** AA, LR6, UM3 (not included)

