

Philips Original radio mini

Bluetooth®

DAB+, FM Dual alarm, Kitchen timer 4 W



**ORT2300C** 

## Control your Original radio mini wirelessly

### with free DigitalRadio app

Get smooth grooves with this Original radio mini. A modern interpretation of the iconic Philetta delivering DAB+ and FM radio, as well as music from smart devices wirelessly via Bluetooth. A built-in kitchen timer adds a touch of convenience.

### High-fidelity radio experience

- Bluetooth music streaming from your smartphones or tablet
- DAB+ and FM compatible for a complete radio experience
- More channels enjoyed with 20 DAB and 20 FM preset stations

### Easy to use

- · Auto time synchronisation ensures accurate time without fuss
- · Large backlit LCD display for easy viewing in low light
- Built-in countdown timer for convenience in the kitchen
- · Audio-in for easy portable music playback

### Start the day your way

- Weekday/weekend alarm setting to complement your lifestyle
- Dual alarm to wake you and your partner at different times
- Sleep timer helps you to drop off to your favourite music

### Contemporary retro design

• Contemporary reinterpretation of the iconic Philetta design



# Highlights

### Iconic Philetta design

Inspired by 1955 Original Radio - This original radio mini carries forward the iconic elements of the legendary 1955 Philips radio, also known as Philetta "BF 102 U". At the time this compact radio wowed audiences with its simple design, big sound and crystal clear reception. Philips radio heritage dates back to 1927. Over the decades, many models have become renowned radio icons and collectors' items.

### **DAB+** and **FM** compatible

DAB+ and FM compatible for a complete radio experience

### 20 DAB & 20 FM preset stations



With 20 DAB and 20 FM preset stations, your favourite channels are always only the push of a few buttons away. To program a preset, simply tune into the desired station, then press and hold the preset button. This quick procedure allows the radio frequency to be automatically stored – for easy access whenever you like.

### Auto time synchronisation



With the automatic time setting function in your clock radio, you do not ever have to set

the time. The clock synchronises with radio signals automatically, even when it is switched off. It updates itself within one minute when there is an immediate need for adjustment, and makes routine synchronisations with radio signals to ensure it keeps accurate time always. From the first time you take the clock radio out of the box, to the time a power outage occurs, you can depend on your Philips product to give you the right time, fuss-free and reliably.

### **Built-in countdown timer**



This clock radio provides the best in convenience for everyday life. A built-in countdown timer helps keep an eye on what is being cooked, ensuring safety and well-prepared dishes. Now you can walk away from the stove or oven, and relax with a bit of TV, or do other chores around the home. Once the time is up, a buzzer will sound, reminding you that your meal is ready to be served.

### Large backlit LCD display



Backlit LCD display ensures easy viewing and operation in low light conditions, and provides clear information at a glance.

### Weekday/weekend alarm



Designed with modern day lifestyles in mind, this clock radio has a dual alarm feature, allowing you to set different alarm times for weekdays and weekends or even vary the alarm settings for couples. The alarm settings can be tailored for the same alarm times for the entire week from Monday to Sunday. Or you can set the alarm for an early start on weekdays from Monday to Friday, and lazy lieins for Saturday and Sundays. Whichever you choose, this convenient feature saves you from the hassle of fiddling with different alarm times every single night.

### **Dual alarm**



The Philips audio system comes with two alarm times. Set one alarm time to wake you up and the other time to wake up your partner.



















## Specifications

### Bluetooth® wireless technology

• Version: BT 2.1

• Profiles: A2DP, AVRCP

### Clock

• Type: Digital

• Time format: 12 H, 24 H

- No. of alarms: 2
- Alarm source: DAB radio, FM radio, Buzzer
- 24-hour alarm reset
- Snooze (repeat alarm): Yes, 9 mins
- Sleep timer: 15/ 30/ 60/ 90/ 120 mins

### Tuner/Reception/Transmission

- Tuner bands: DAB (Band III), FM
- · DAB: smart scan, menu, info display
- DAB frequency range: 174.9 239.2 MHz
  FM frequency range: 87.5 108 MHz
  No. of preset stations: 20 (DAB), 20 (FM)

- · Auto digital tuning
- · Antenna: FM antenna

### Convenience

- Display Type: LCD
- Display brightness: High/ Mid/ Low

### Sound

- · Sound system: mono
- Volume control: rotary (digital)

### Loudspeakers

· Built-in speakers: 1

### **Connectivity**

- Bluetooth
- Audio in (3.5 mm)

### **USB** Charging

- Yes
- 5 V, 1 A

### **Power**

- · Power type: AC input
- AC power input: 100-240 V, 50/60 Hz

### **Dimensions**

- Product dimensions (WxDxH): 245 x 133 x 122 mm
- Packaging dimensions (WxDxH): 336 x 158 x 183
- Product weight: 1.1 kg

### **Accessories**

- · AC/DC adapter: with detachable plug (VDE and UK)
- · Quick start guide
- Warranty: Warranty leaflet



Issue date 2014-08-30

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 2.0.5

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 01178

EAN: 08 71258 16811 97 www.philips.com