



Philips
Car entertainment system

15.2 cm (6")

2-way
170W Peak



CSQ605

Your mobile music theater

with 2-way stereo for vivid sound

Feel your music with the Philips Car stereo speakers CSQ605. These 16.5cm 2-way speakers have peak power at 170W, and feature a light polypropylene cone with a soft PEI dome tweeter for you to enjoy vivid music details in clear sound.

Vivid sound on the road

- 30W RMS power handling
- Light polypropylene cone for clear sound delivery
- Soft PEI dome tweeter for warm and textured tones
- Sensitive cloth surround for maximum sound details
- Strong ferrite magnet for high power performance

High durability, sustainable performance

- Sturdy polypropylene cone for all-weather performance
- Endurance and performance stability in extreme conditions

Easy to use and install

- Fits perfectly in all 16.5cm speaker openings
- Simple wires plug-in for designated speaker terminals

PHILIPS

Specifications

Sound

- Output power (RMS): 30W
- Peak Music Power: 170W
- Sensitivity: 88dB
- Frequency response: 30-25k Hz
- Impedance: 4 Ohms

Loudspeakers

- Speaker type: Coaxial speaker
- Number of ways: 2-way
- Speaker size: 16.5cm (6.5")
- Number of Loudspeakers: 2

Woofers

- Diaphragm: Cone
- Diaphragm material: Polypropylene
- Surround: Cloth
- Voice coil: Single
- Voice coil material: Copper
- Magnet: Ferrite

- Magnet mass: 7.7 Oz
- Damper: Conex

Tweeter

- Size: 38mm (1-1/2")
- Diaphragm: Dome
- Diaphragm material: PEI
- Magnet: Neodymium

Accessories

- Quick start guide: English, Spanish, Portuguese, Russian
- Cables: Speaker wires

Dimensions

- Product dimensions (W x H x D):
173 x 81 x 173 mm
- Mounting depth: 58 mm
- Tweeter protrusion: 3 mm



Issue date 2014-02-13

Version: 1.0.4

12 NC: 8670 000 65502
EAN: 69 23410 70353 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com