

Philips Micro Hi-Fi System

MP3/WMA-CD playback USB Direct

MCM239

Obsessed with sound

Sound that fits your home

Great sound in a compact, elegant design. The classic MCM239 delivers dynamic sound performance and the essential functionalities that will let you enjoy music just the way you like it.

Enrich your sound experience

- USB Direct for MP3/WMA music playback
- Play MP3/WMA-CD, CD and CD-RW
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- · Convenient line-in jack for portable music playback
- 10W RMS total output power

Start the day your way

- Wake up and sleep timer functions
- Digital tuning with 40 preset stations for extra convenience

Fits any space, any lifestyle

- · Compact design
- Easy-to-use remote control included



Highlights

USB Direct

With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically

adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume

settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

















Specifications

Sound

- Output power: 2×5 W, 2×10 W music power
- Sound enhancement: digital sound control 4 modes, Dynamic Bass Boost

Loudspeakers

- Speaker drivers: 4" woofer, full range
- · Speaker types: bass reflex speaker system

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/program
- Others: ID3-tag support
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop

Tuner/Reception/Transmission

- Tuner bands: FM stereo, MW
- Station presets: 40
- Antenna: FM antenna, MW antenna
- RDS: program type, station name, radio text, RDS clock set
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in
- USB: USB host

Convenience

- Alarms: CD alarm, radio alarm, USB alarm
- Clock: on main display, sleep timer
- Loader type: front
- Display type: LCD display
- · Backlight color: blue

Accessories

- Cables/Connection: AC-DC adapter
- Remote control: 24-key with lithium battery
- Others: FM/MW antenna, Quick start guide, stand
- User Manual: multi-languages

Dimensions

- Gross weight: 5.8 kg
- Main speaker dimensions (W x D): 158 x 118 mm
- Main speaker height: 250 mm
- Main unit depth: 160 mm
- Packaging width: 350 mm
- Main unit height: 250 mm
- · Packaging height: 310 mm
- Main unit width: 211 mm
- Packaging depth: 284 mm

Power

• Power supply: 100 - 240V AC, 50/60Hz

Green

• Eco Power standby: 1 W



Issue date 2014-02-06

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 1.0.7

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 32016 EAN: 87 12581 34928 8

www.philips.com