

Philips
DVD player with HDMI
and USB

HDMI 1080p
DivX Ultra
Karaoke

DVP3388K



The best DVD player for your HDTV

with HDMI 1080p upscaling

Be impressed with this Philips DVD player with HDMI digital video and audio connection. Step into another home entertainment arena as you immerse yourself with High Definition video (720p / 1080i/1080p).

Bring audio and video to life

- HDMI 1080p upscales to high definition for sharper pictures
- Screen Fit for optimal viewing every time

Play all your movies and music

- Windows Media Video playback for movies from your PC
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW
- Plays WMV, DivX, WMA, MP3 and HD JPEG photos
- DivX Ultra Certified for enhanced playback of DivX videos

Connect and enjoy multiple sources

- Hi-Speed USB 2.0 Link plays video/music from USB flash drive
- Media Copy transfers photos & music to USB flash drives

Easy to set up and use

- One-touch MP3 creation directly from CDs onto USB sticks
- EasyLink to control all HDMI CEC devices via a single remote

PHILIPS

Highlights

HDMI 1080p

HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multichannel audio, without conversions to analog - delivering perfect picture and sound quality, completely free from noise.

Hi-Speed USB 2.0 Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. Hi-Speed USB devices have a data transfer rate of up to 480 Mbps - up from the 12 Mbps in original USB ones. With Hi-Speed USB 2.0 Link, all you have to do is plug in your USB device, select the movie, music or photo and play away.

One-touch MP3 creation

Convert the contents of your favorite CDs to MP3 files on your Philips product, and store it directly on a thumbdrive or on your portable media player through a USB cable. Enjoy the convenience of creating MP3 files right in your living room, without a PC, and even while the CD is playing.

EasyLink

EasyLink lets you control multiple devices like DVD players, Blu-ray players, soundbar speaker, Home theater and TV's etc. with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC enabled equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

Media Copy

Share your photos and music with family and friends in your living room – and elsewhere. Simply copy the files onto your USB thumb

drive and carry your favorites with you wherever you go.

Screen Fit

Whatever you're watching, and on any TV, Screen Fit ensures that the picture fills the whole screen. Annoying black bars on the top and bottom are eliminated, without any tedious manual adjustments to make. Simply press the Screen Fit button, choose the format and enjoy your movie in full-screen

DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.



Specifications

Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling, High Def (720p, 1080i, 1080p), Smart Picture, Video upscaling, Video Upscaling(720p, 1080i/p)

Sound

- D/A converter: 24 bit, 192 kHz
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Distortion and Noise (1kHz): 65 dB
- Crosstalk (1kHz): 70 dB
- Dynamic Range (1kHz): 80 dB
- Sound System: Dolby Digital, DTS

Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/SVCD, DVD, DVD+R/+RW, DVD-R/-RW, DivX, DVD-Video
- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, WMV
- Video disc playback system: PAL, NTSC

Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW, Audio CD
- Compression format: PCM, MP3, Dolby Digital, WMA, DTS
- MP3 bit rates: 32 - 320 kbps

Still Picture Playback

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Zoom,

High Definition Resolution, Slideshow with MP3 playback

Connectivity

- Front / Side connections: Microphone, USB
- Rear Connections: Composite video (CVBS) output, Digital coaxial out, ComponentVideo out, Progressive, Analog audio Multi-channel out, HDMI output, Digital optical out

Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: English, Russian

Power

- Power supply: 110-240V, 50/60 Hz
- Power consumption: < 12 W
- Standby power consumption: < 0.3 W

Accessories

- Included accessories: Audio/Video cable, Quick start guide, World Wide Warranty leaflet, Remote Control, 2 x AAA Batteries, User Manual, Warranty Leaflet

Dimensions

- Set dimensions (W x H x D): 360 x 38 x 210 mm
- Packaging dimensions (W x H x D): 415 x 82 x 282 mm
- Set weight: 1.4 kg

Multimedia Applications

- Multimedia connections: USB memory class device
- Playback Formats: DivX, JPEG Still pictures, MP3



Issue date 2017-04-09

Version: 1.0.7

12 NC: 8670 000 50855
EAN: 87 12581 47294 8

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com