

Philips Headphones with mic

14.8-mm drivers/open-back
Ear bud



SHE3015BK



Extra bass

Soft body for comfy fit

Philips SHE3015 headphones with soft body earbuds offer a comfortable fit. Available in eye-catching colours. The built-in mic and control make hands-free talking on mobile easy.

Enjoy quality sound

- 14.8-mm (0.6") speaker drivers for high quality sound
- Neodymium magnets enhance bass performance and sensitivity

Ultimate wearing comfort

- Soft body ensures a comfortable fit
- Rubberised front caps for wearing comfort

Design for convenience

- Flexi-Grip design for durability
- Built-in microphone switches you from music to phone calls



SHE3015BK/00

Specifications

Design

· Colour: Black

Sound

- · Acoustic system: open
- Magnet type: Neodymium
- · Voice coil: copper
- · Diaphragm: PET
- Impedance: 16 ohm
- Maximum power input: 25 mW
- Sensitivity: 107 dB
- Speaker diameter: 14.8 mm
- Type: Dynamic
- Frequency response: 9 22 000 Hz

Connectivity

- · Cable Connection: two-parallel, symmetric
- · Cable length: 1 m
- Connector: 3.5 mm
- Finishing of connector: nickel plated
- · Type of cable: copper

Packaging dimensions

- EAN: 69 23410 73225 2
- Packaging dimensions (W \times H \times D): 5.2 \times 17.5 \times 2.8 cm
- Gross weight: 0,0339 kg

- Net weight: 0.0134 kg
- Number of products included: 1
- · Packaging type: Soother
- Tare weight: 0,0205 kg
- Type of shelf placement: Soother

Inner Carton

- Gross weight: 0,1287 kg
- GTIN: 2 69 23410 73225 6
- Inner carton (L x W x H): 17.9 x 8 x 6 cm
- Net weight: 0.0402 kg
- Number of consumer packages: 3
- Tare weight: 0,0885 kg

Outer Carton

- Gross weight: 1,2586 kg
- GTIN: 1 69 23410 73225 9
- Outer carton (L \times W \times H): 34.5 \times 19.7 \times 16.3 cm
- Net weight: 0.3216 kg
- Number of consumer packages: 24
- Tare weight: 0,9370 kg

Product dimensions

- Product dimensions (W x H x D):
- 1.6 x 2.1 x 1.25 cm
- Weight: 0.0134 kg

Highlights

14.8-mm (0.6") speakers
Large 14.8-mm (0.6") speaker drivers squeezed into earbud headphones deliver high quality sound.

Flexi-Grip

A soft, flexible part protects the cable connection from damage that otherwise would occur due to repeated bending.

Neodymium magnets

Neodymium is the best material for producing a strong magnetic field for greater sensitivity in a voice coil, better bass response and higher overall sound quality.

Rubberised front cap

A rubberised front cap provide a totally soft body for wearing comfort.

Soft body

The transparent, rubberised headphone body moulds itself to the shape of the ear for comfortable

Built-in microphone

The built-in microphone lets you switch from listening to music to taking phone calls - easily, so you'll always stay connected with what matters most to you.



Issue date 2017-07-12

© 2017 Koninklijke Philips N.V. All Rights reserved.

Version: 1.2.4

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 17187 EAN: 06 92341 07322 52

www.philips.com