

Philips  
Micro Hi-Fi System

MP3

MCM390



## Enjoy MP3-CD music the way you like it

Compact and stylish, this elegant wood-finished beauty packs a powerful punch. Combining superb performance and essential functionalities without compromising on aesthetics, just sit back and enjoy music the way you like it.

### **Longer listening, greater enjoyment**

- 10 hours of MP3-CD music

### **Enrich your sound experience**

- Incredible Surround™ for enhanced audio enjoyment
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x15W RMS / 700W PMPO

### **Start the day your way**

- Wake-Up and Sleep Timer
- Logic tape deck
- Digital tuning with 40 preset stations for extra convenience

### **Sounds great too**

- Elegant wood-finished speakers

**PHILIPS**  
sense and simplicity

# Highlights

## 10 hours of MP3-CD music



MP3 stands for "MPEG 1 Audio layer-3".MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

## Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the

virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

## Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control

makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



# Specifications

## Sound

- Output Power: 700 watts PMPO
- Sound Enhancement: Incredible Surround, Digital Sound Control 4 modes, Dynamic Bass Boost

## Loudspeakers

- Main Speaker: 2 way, Bass Reflex Speaker System, 4" woofer, Piezo tweeter, Speaker grilles detachable

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- ID3-tag support
- Loader Type: Top
- Cassette Deck Technology: Logic
- Cassette Playback Modes: Electronic Speed Control, Full Auto Stop, Tape Counter

## Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording, Timer for recording from tuner, Automatic Recording Level

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW

- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

## Connectivity

- Aux in: Line in
- Headphone: 3.5 mm
- Other connections: FM Antenna, MW Antenna

## Convenience

- Alarms: CD Alarm, Radio Alarm, Tape alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Backlight color: Blue
- Eco Power Standby: 1 watt

## Accessories

- Included Accessories: FM/MW Antenna
- Remote control: 21-key

## Dimensions

- Set dimensions (W x H x D): 148 x 235 x 258 mm
- Main speaker dimensions (W x H x D): 142 x 235 x 212 mm
- Packaging dimensions (W x H x D): 342 x 312 x 446 mm
- Weight incl. Packaging: 8.43 kg



Issue date 2009-05-03

Version: 3.0.6

12 NC: 9073 100 12371  
EAN: 87 10895 86364 3

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)