



Philips  
Micro music system

## DVD

CD, MP3-CD, USB, FM  
2.1 system, with subwoofer  
70W max

MCD1165

# Enjoy great movie experience

## Obsessed with sound

Be assured of cinematic room-filling sound with the Philips DVD micro system MCD1165. The speaker system backed with 70W RMS maximum output power allows you to feel every sound effect. Also features USB Direct for photo and music playback.

### Enjoy your favorite movies and music

- Play DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD
- Dolby Digital for ultimate movie experience
- USB Direct for photos and MP3/WMA music playback
- Karaoke for endless singing entertainment at home

### Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- 70W RMS maximum output power
- Digital Sound Control for optimized music style settings

### Easy to use

- FM digital tuning to preset up to 20 stations
- Motorized CD loader for convenience access
- Wake up and sleep timer functions

# PHILIPS

Micro music system  
DVD CD, MP3-CD, USB, FM, 2.1 system, with subwoofer, 70W max

MCD1165/55

# Highlights

## Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system

extends the overall low frequency sounds to create a whole new dimension of deep bass.

## Karaoke for endless singing



Karaoke for endless singing entertainment at home

## Digital Sound Control



Digital Sound Control offers you a choice of pre-set Balance, Clear, Powerful, Warm and Bright controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



# Specifications

## Sound

- Sound Enhancement: Digital Sound Control
- Sound System: Dolby Digital
- Maximum output power (RMS): 70W

## Loudspeakers

- Speaker drivers: 3.5"
- Subwoofer types: passive

## Video Playback

- Playback Media: DivX, DVD-Video, Picture CD, Video CD/SVCD, DVD+R/+RW, DVD-R/-RW
- Disc Playback Modes: A-B Repeat, Angle, PBC, Slow Motion, Zoom, Parental control, Disc Menu, Fast Backward, Fast Forward, OSD, Resume Playback from Stop
- DVD Region.: 4
- Video Enhancement: Progressive Scan

## Audio Playback

- Playback Media: MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play, Fast Forward/Backward, Next/Previous Track Search
- Loader Type: Motorised, Tray
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

## Still Picture Playback

- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow with MP3 playback
- Playback Media: Picture CD, CD-R/RW, DVD+R/-RW

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo

- Auto digital tuning
- Tuner Enhancements: Auto Store
- Station presets: 20

## Connectivity

- Video Output - Analog: Composite CVBS (yellow cinch), Component Y Pb Pr (cinch)
- Audio Connections: Analogue Audio In (L/R)
- USB: USB host
- Microphone: Microphone socket

## Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm, USB alarm
- Clock: On main display
- Indications: DIM mode

## Accessories

- Included accessories: Composite video cable (Y), AC Power Cord
- User Manual: Multi-languages
- Remote control

## Dimensions

- Gross weight: 7.5 kg
- Main unit depth: 220.4 mm
- Main unit height: 119 mm
- Main unit width: 180 mm
- Main speaker dimensions (W x D): 127 x 160 mm
- Main speaker height: 170 mm
- Subwoofer dimensions (W x H x D): 170 x 265 x 250 mm
- Packaging depth: 557 mm
- Packaging height: 244 mm
- Packaging width: 557 mm

## Power

- Power supply: 100-240V, 50/60 Hz



Issue date 2014-06-12

Version: 1.0.2

12 NC: 8670 001 02907  
EAN: 87 12581 68751 9

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)