



Philips
5.1 Home theater

300W RMS power
DVD playback

HTS3181

Spectacular surround sound with superb clarity

Just like in the movies

Relax and immerse yourself in movies in your very own living room. Enjoy high quality multi-channel surround sound, along with Karaoke Scoring, and playback from USB drives, and from practically any type of disc

Bring audio and video to life

- Dolby Digital and Pro Logic II surround sound
- Advanced Class D Amplifier for compact, powerful sound
- Karaoke Scoring for fun and exciting song contests at home

Connect and enjoy multiple sources

- USB Media Link for media playback from USB flash drives

Easy to set up

- Easy-fit™ connectors with color-coding for a simple set-up

Play all your movies and music

- DivX Ultra Certified for enhanced playback of DivX videos
- Built-in FM tuner
- Plays DivX, MP3, WMA and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL

PHILIPS

Specifications

Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan

Sound

- Total Power (RMS): 300 W
- Output power (RMS): 6 x 50W
- D/A converter: 24 bit, 192 kHz
- Frequency response: 40-20000 Hz
- Signal to noise ratio: >60 dB
- Sound System: Dolby Digital, Dolby Prologic II, Stereo
- Sound Enhancement: Class "D" Digital Amplifier, Night Mode
- Equalizer settings: Action, Classic, Concert, Drama, Rock, Sports, Jazz, Night

Video Playback

- Playback Media: CD-R/CD-RW, DVD+R/+RW, DVD-R/-RW, DVD-Video, Video CD/SVCD, USB flash drive
- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, MPEG4
- Video disc playback system: PAL, NTSC

Audio Playback

- Playback Media: Audio CD, CD-R/RW, DVD+R/+RW, DVD-R/-RW, USB flash drive
- Compression format: MP3, WMA
- MP3 bit rates: 32-256 kbps and VBR

Still Picture Playback

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, USB flash drive
- Picture Compression Format: JPEG
- Picture Enhancement: Rotate, Zoom, Slideshow with music playback

Tuner/Reception/Transmission

- Tuner Bands: FM
- Number of Preset Channels: 40

Connectivity

- Rear Connections: Composite video (CVBS) output, FM Antenna, Easy-Fit Speaker Connectors,

Component Video output, Analog audio Left/Right in 2x
• Front / Side connections: Microphone input 3.5mm jack, USB

Power

- Power supply: 110-240V, 50/60 Hz
- Standby power consumption: < 1 W
- Power consumption: 60 W

Loudspeakers

- Satellite speaker drivers: 3" full range woofer
- Satellite speaker impedance: 4 ohm
- Satellite speaker freq range: 150-20000 Hz
- Center Speaker: Magnetically shielded
- Center speaker drivers: 3" full range woofer
- Center freq range: 150-20000 Hz
- Center speaker impedance: 8 ohm
- Subwoofer driver: 6.5" high efficiency woofer
- Subwoofer type: Passive
- Subwoofer impedance: 8 ohm
- Subwoofer freq range: 45 - 150 Hz

Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, CVBS video cable, FM antenna, User Manual, Quick start guide, World Wide Warranty leaflet, VDE to 2-pin Flat Adaptor

Dimensions

- Set dimensions (W x H x D): 360 x 55 x 332 mm
- Set weight: 2.72 kg
- Surround Speaker dimensions (W x H x D): 100 x 100 x 75 mm
- Surround speaker Weight: 0.38 kg
- Center speaker dimensions (W x H x D): 100 x 100 x 75 mm
- Center Speaker Weight: 0.38 kg
- Subwoofer dimensions (W x H x D): 123 x 310 x 369 mm
- Subwoofer Weight: 3.54 kg
- Packaging dimensions (W x H x D): 564 x 302 x 380 mm
- Weight incl. Packaging: 10.4 kg

Highlights

Dolby Digital and Pro Logic II

A built-in Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

Advanced Class D Amplifier

Advanced Class D Amplifier for compact, powerful sound

DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

Karaoke Scoring

Add a dash of fun to your Karaoke sessions with Karaoke Scoring. Allow your performance to be judged for further improvement, or for friendly competitions. Karaoke Scoring automatically rates your singing and gives you a humorous picture that is tied to how well you did. The fun never ends.

Plays it all

Play virtually any media format you want - whether they be DivX, MP3s, WMA or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

Plays it all

Play virtually any disc you want - whether they be CDs, (S)VCDs, DVDs, DVD+R, DVD-R, DVD+RW, DVD-RW or DVD+R DL. Experience unbeatable flexibility and the convenience of playing all your discs on the one device.

Easy-fit™ connectors

Color-coded connectors provide a simple and user-friendly solution to connect the speakers and subwoofer to the center unit of the home entertainment system simply by plugging the connectors in the matching colored interface at the rear of the center unit.



Issue date 2014-02-10

Version: 9.0.3

12 NC: 8670 000 53742
EAN: 87 12581 48892 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.

* Adaptor supplied is needed for all Latin American countries, except in Brazil.