

Philips Universal remote control 6in1

SRU7060



Home entertainment control

Operates more than 1200 brands

The superiority technology in this stunning universal remote control empowers you to control your complete home entertainment center from a stylish design unit.

Single control solution for most devices & brands

- 6-in-1 remote for your TV, DVD, STB, AMP, VCR and CD
- Convenient IR learning from another remote
- Ready for use with Philips equipment

Great convenience

- Eye-catching chrome-plated finish
- The user interface lights up when you pick up the device
- · Control multiple devices with a single touch

Easy setup

- Automatically searches for your equipment brand
- · Code entry for direct setup of your remote control
- For questions and assistance call our URC service line
- URC support service via dedicated website



Specifications

Convenience

- Supported devices: TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP
- TV functions: Program up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu control, Color/Brightness control, Teletext keys, Fast text keys, Previous program, Sleep/timer, 16:9, Guide, info
- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys
- SAT/CBL functions: Digit keys, Menu control, Guide, info, Favourites, Text functions
- VCR functions: Transport keys (6), Showview, VCR plus, Menu control
- Backlight
- · Backlight color: Red
- Preprogrammed for Philips
- · Simple system setup
- Copy key function
- Installation steps: 2
- Language support: GB/F/D/NL/DK/S/N/FIN/I/E/P
- Number of keys: 39 • Regulatory approvals: CE Mark
- Splash proof
- Teletext enhancements: Fast text
- Tilt: Tilt sensor
- Ease of Installation: Autosearch
- Accessories
- Battery: Yes, 1.5V Battery AA LR6

- **Infrared Capabilities**
- · Learning IR codes
- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: Over 300
- Carrier frequency range: 28 70kHz
- Transmission angle: 90 degree
- · Learning frequency range: 30 kHz 60 kHz
- Operating distance: 33 ft (10 m)

Power

- Battery lifetime: 12 Months
- Battery type: AA / LR6 Alkaline
- Number of batteries: 2

Outer Carton

- · Length: 354 mm
- Width: 121 mm
- Height: 177 mm

• Quantity: 3

• EAN/UPC/GTIN: 87 10895 93581 4

- **Packaging Data** • 12NC: 908210006466
- EAN/UPC/GTIN: 87 10895 93580 7
- Length: 338 mm
- Height: 45 mm
- Width: 155 mm



SRU7060/10

Highlights

Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to it.

Chrome plated design

Stylish chrome finish that looks good and complements the latest equipment design.

Automatic backlighting

No more searching for buttons in the dark, because when you pick up the remote control, the keys (or LCD display) automatically light up.

One-touch convenience

One-touch control allows you to perform multiple commands with one press of a button via a macro. A macro combines a string of pre-programmed commands under one single button. Therefore, it simply takes one button press to execute a series of functions.

Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.

Direct code entry

If your remote doesn't automatically find your equipment brand you can always manually key in its digit code from the comprehensive list supplied in the instructions for use.



Issue date 2017-04-04

© 2017 Koninklijke Philips N.V. All Rights reserved.

Version: 2.1.8

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 9082 100 06466 EAN: 87 10895 93580 7

www.philips.com