

Philips  
CD Soundmachine with  
Dynamic Bass Boost

MP3

AZ1037



## All-in-one, MP3 music with enriched bass

You take pleasure in the simple things in life and delight in convenience. The sleek and portable AZ1037 lets you indulge in the pleasures of enjoying your favorite music in enriched bass sound with the help of easy-to-use functions.

### Enjoy your music from different sources

- MP3-CD playback means MP3 plays like a normal audio CD.
- FM/MW stereo tuner
- Autostop stereo cassette deck

### Enhanced bass performance

- Dynamic Bass Boost for deep and dramatic sound

### Easy to use

- CD to tape synchro-start recording
- 20-track CD programmable
- Multi-functional LCD display
- Stereo headphone socket
- Handy remote control

**PHILIPS**  
sense and simplicity

# Specifications

## Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play
- Programmable Tracks: 20
- Cassette Deck Technology: Mechanical
- Number of decks: 1

## Tuner/Reception/Transmission

- Tuner Bands: FM, MW
- Antenna: FM Antenna

## Sound

- Output power (RMS): 2X1.2W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Volume Control: rotary

## Convenience

- Display Type: LCD

## Connectivity

- Headphone: 3.5 mm

## Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

## Accessories

- Included Accessories: AC Power Cord, User Manual, Warranty certificate
- Remote control

## Dimensions

- Packaging dimensions (W x H x D): 325 x 180 x 280 mm
- Product dimensions (W x H x D): 290 x 143 x 240 mm
- Weight: 1.99 kg
- Weight incl. Packaging: 2.64 kg



# Highlights

## MP3-CD playback

MP3 stands for "MPEG 1 Audio layer-3".MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

## Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## CD synchro-start recording

CD to tape synchro-start recording

## 20-track CD programmable

The CD programmable playback feature allows you to enjoy your favorite tracks in the sequence you want.

## Handy remote control

Handy remote control



Issue date 2009-11-06

Version: 1.0.3

12 NC: 8670 000 32732  
UPC: 6 09585 14008 0

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)