

Philips Mini Hi-Fi System

MP3/WMA-CD playback

FWM75

# wOOx Technology

## Hear the Bass. Feel the Difference!

For those who value technology that enhances experiences, FWM75 has it all. Immerse yourself in the power of wOOx Technology and fully appreciate your favorite MP3 and WMA music in dynamic and rich sound.

## Powerful sound you can hear and feel

- $2 \times 150$ W RMS/  $2 \times 300$ W music power/4000W PMPO
- Class 'D' digital amplifier for quality sound performance
- Front firing wOOx Technology speakers

## Longer listening, greater enjoyment

- 3-disc changer for convenient multi-disc playback
- 60 hours of WMA-CD or 30 hours of MP3-CD music playback
- Dual Logic Tape Deck with auto replay

## **Ready for gaming**

- · Gameport connection to your game console
- Game Sound modes for different types of games
- MIX-IT for mixing the game sound with your favorite music



## Highlights

#### 2x150W RMS/2x300W music power

 $2 \times 150W$  RMS/  $2 \times 300W$  music power/ 4000W PMPO

#### Class 'D' Amplifier

Class 'D' Digital Amplifier takes an analog signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, Class 'D' Digital Amplifier has greater than 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

### Front firing wOOx Technology

Front firing wOOx Technology speakers

#### 3-disc changer

With a three-disc changer for music playback, you can choose between three different CDs inside the device at any one time. This convenient feature allows you to savor a variety of music while saving you precious time from changing CDs frequently.

#### 60 hours of WMA-MP3-CD music

60 hours of WMA-CD or 30 hours of MP3-CD music playback

### **Dual Logic Tape Deck**

Dual Logic Tape Deck with auto replay

#### **Gameport connection**

Gameport connection to your game console

#### **Game Sound modes**

Game Sound modes for different types of games

#### MIX-IT for mixing game sound

MIX-IT for mixing the game sound with your favorite music

















## **Specifications**

#### Sound

- Output Power: 2 x 300W music power
- Sound Enhancement: Class "D" Digital Amplifier, wOOx technology, Incredible Surround, Digital Sound Control, Virtual Ambience Control, Game Sound, MIX-IT

#### Loudspeakers

- Main Speaker: 3 way, Bass Reflex Speaker System,
  6.5" woofer, wOOx Bass Radiator, 2" tweeter,
  Piezo, Speaker grilles detachable
- Number of Loudspeakers: 2

#### **Audio Playback**

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA
- Loader Type: 3 CD Carousel
- Number of Discs: 3
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat/one/all/ program, Repeat/one/disk/program, 99-Track Programmable
- Cassette Deck Technology: Logic
- Number of decks: 2
- Cassette Playback Modes: Full Auto Stop

#### **Audio Recording**

- · Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording, Automatic Recording Level

## Tuner/Reception/Transmission

- · Auto digital tuning
- Tuner Bands: FM Stereo, MW
- Tuner Enhancements: Auto Store, Easy Set (Plug &

## Play)

- Station presets: 40
- RDS: Station Name, RDS Clock Set, Radio Text, Program Type, News

#### **Connectivity**

- Aux in: Line in, Gameport
- · Headphone: 3.5 mm
- Other connections: Composite video (CVBS) out, FM Antenna, MW Antenna

#### Convenience

- · Alarms: CD Alarm, Radio Alarm, Sleep timer
- · Clock: On main display
- Display Type: FTD
- Eco Power Standby: 1 watt
- Indications: DIM mode, track, time, date, Cd functions, album number, album name

#### **Accessories**

- Remote control: 32-key with 2xAA Batteries
- Included accessories: AC Power Cord, FM/MW Antenna

#### **Dimensions**

- Set dimensions (W  $\times$  H  $\times$  D): 265  $\times$  322  $\times$  390 mm
- Main speaker dimensions (W x H x D): 240 x 358 x 230 mm
- Packaging dimensions (W x H x D): 624 x 412 x 510 mm
- Weight incl. Packaging: 20.5 kg

#### Power

- Standby power consumption: < 1W
- Power supply: 200-240 V, 50Hz



Issue date 2014-02-11

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 3.0.4

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 9073 100 12442 EAN: 87 10895 86622 4

www.philips.com