



Wireless speaker

- Bluetooth®
- 2.5 W Output Power
- 8 hours play time
- IPX7 waterproof

TAS1505B/00

Party in your pocket

Put a party in your pocket with the Bluetooth speaker that's small enough to hang from your wrist! This petite speaker is completely waterproof and gives you surprisingly punchy sound for its size.

Benefits

Waterproof and ready to go

- Tough and IPX7 waterproof
- 8 hours play time. 2.5 hours charge time
- Passive radiator. Punchy bass
- 1.6" driver. Vibrant sound

Light up the music

- Rock-solid Bluetooth connection

- Up to 20 m wireless range

Take the party with you

- Pick your colorway. Show your style
- Dimensions: 78x64x64 mm
- Matching carry strap included

PHILIPS

Features

Tough and IPX7 waterproof

This portable Bluetooth speaker is IPX7-rated—which means it can withstand total immersion in water up to 1 m deep for up to 30 minutes. You can party in the shower, by the pool, or even in the pool! The wireless range is 20 m.

8 hours play time

Sound stays clear even when you play the music loud, and a passive radiator boosts the bass. You get 8 hours play time, and a full charge takes 2.5 hours. The Bluetooth connection is stable, and pairing is simple.

Pick your colorway

Always do you. This small Bluetooth speaker is available in several colorways, so you can rock your style. The matching carry strap makes it easy to tote the speaker wherever you go.

Specifications

[field not found 'disclaimer_text']

Sound

Output power (RMS)	2.5W
Output power (MAX)	5W
Frequency response	150 Hz - 18 KHz
Sound System	Mono

Battery Capacity	480mAh
Operating time on battery	8 hr
Charging time	2.5 hr
Power bank	No

Loudspeakers

Number of sound channels	1
Driver configuration	Full range
Number of full range drivers	1
Full range driver diameter	25mm

Accessories

Cable	USB charging cable
Included accessories	carrying strap Quick install guide World Wide Warranty leaflet Warranty Card

Connectivity

Bluetooth profiles	A2DP
Bluetooth range	Line of sight, 20m or 66ft
Bluetooth version	5.0
Type of cable	USB charging cable (Type-C)
DLNA Standard	No
Multiple speaker connection	No

Design

Color	Black
-------	-------

Product dimensions

Depth	6.4 cm
Height	7.8 cm
Weight	0.14 kg
Width	6.4 cm

Compatibility

Smartphone/tablet	No
APP control	

Packaging dimensions

Depth	8.2 cm
Gross weight	0.22 kg
Height	18.5 cm
Nett weight	0.18 kg
Number of products included	1
Packaging type	Blister
Tare weight	0.04 kg
Type of shelf placement	Hanging
Width	10 cm
EAN	48 95229 11101 1

Convenience

Water resistance	IPX7
Built-in microphone	No
Display screen	No
Handsfree calling	No
Light Effect	No

Power

Battery type	lithium (built-in)
--------------	--------------------



data subject to change
2023, June 18

Version: 6.0.2
EAN: 4895229111011

© 2023 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com