

Compelling sound quality

Big bass 12 W sound for multimedia enjoyment



The MMS222 speaker system is the best way to add stereo experience for your music, Internet and multimedia PC applications.

Your computer never sounded so good

- Enjoy PC audio with the quality of a home audio system
- Over 75 years of audio experience

Experience true multimedia

- Compatible with music, games, film & Internet audio sources
- Easy to connect to either a PC or a laptop

Hear every detail

- Bass reflex speakers deliver a powerful, deeper bass
- Dynamic Bass Boost delivers deeper, more dramatic bass

Easy to use

- Labelled and colour coded connectors get you going in minutes
- Headphone jack for better personal music enjoyment
- Magnetic Shielding eliminates computer screen distortion



PHILIPS

Technical specifications

Sound

- **Bass enhancement:** Digital Bass boost
- **Frequency response:** 120 - 20 000 Hz
- **Music power:** 12 W
- **Output power (RMS):** 2 x 3W
- **Volume Control:** Analogue volume control
- **Wires:** Fixed wires

Loudspeakers

- **Loudspeaker enhancement:** Magnetic shielded LSB

Connectivity

- **Headphone:** 3.5 mm
- **Power:** Built in transformer

Convenience

- Power on indication

Power

- **Power LED indicator:** Blue

Packaging content

- Quick installation guide

Packaging Data

- **I2NC:** 908210003398
- **EAN/UPC/GTIN:** 8710895844574
- **Gross weight:** 1.49 kg
- **Height:** 218 mm
- **Length:** 220 mm
- **Width:** 110 mm
- **Quantity:** 1
- **Tare weight:** 0.2 kg

Outer Carton

- **Quantity:** 5
- **EAN/UPC/GTIN:** 8710895851473
- **Tare weight:** 0.5 kg
- **Gross weight:** 7.95 kg
- **Length:** 565 mm
- **Width:** 235 mm
- **Height:** 230 mm
- **I2NC:** 908210003398

Product highlights

Home audio quality on the PC

Philips has used over 75 years experience at the leading edge of audio to create PC audio products with the same performance as our award winning home audio systems.

Music, games, films, Internet

All types of music, games, films and Internet audio sources can be played, so no matter what you want to hear, we make your multimedia experiences sound more involving than ever.

Bass reflex speaker system

Bass reflex speaker system delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Quick set up

Colour coded cables, clear labelling and easy to understand documentation mean you'll be up and running in minutes

For PC or laptop

Can be connected to either a PC or a laptop

Headphone jack

Magnetic Shielding

Because the powerful magnets in speaker drivers are magnetically shielded, there's no danger of image distortion or damage when placed close to your PC monitor screen.

75 years of audio experience

Philips invented the CD, led the team that wrote the USB audio specification and has produced millions of audio systems, home cinema sets and TV's over many decades. As a leader in audio innovation, you can trust Philips to make PC sound systems of the highest sound quality.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Date of issue 2006-01-11

Version: 3.0

I2NC: 9082 100 03398
EAN: 87 10895 84457 4

Specifications are subject to change without notice.

Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

© 2006 Koninklijke Philips Electronics N.V.

All Rights reserved.

www.philips.com