

## Enjoy music from iPod/iPhone and DAB+ radio

## with this docking station

Let this Philips AJB7038D/10 docking station wake you with favourites from your iPod/iPhone. It delivers powerful bass with the Bass Reflex Speaker system and 20-W RMS power. Dock any iPod/iPhone. Also enjoy free DigitalRadio app with RadioVIS.

### **Enrich your sound experience**

- Play and charge your iPod/iPhone simultaneously
- FM digital tuning with presets
- Bass Reflex Speaker System delivers a powerful, deeper bass
- 20 W RMS total output power

## Easy to use

- Free DigitalRadio app with RadioVIS and control of DAB+/FM
- Dock any iPod/iPhone, even in its case
- · Auto clock synchronisation with iPod/iPhone when docked
- MP3 Link for portable music playback
- Sleep timer helps you to drop off to your favourite music

## Start the day your way

- Wake up to your iPod/ iPhone music or radio tunes
- Gentle wake for a pleasant waking experience
- · Dual alarm to wake you and your partner at different times

Philips docking station for iPod/ iPhone

- DAB+
- Aluminium



## AJB7038D





# **Highlights**

### Free DigitalRadio app

Tune in to radio extras with RadioVIS - a powerful feature provided by RadioDNS, an organisation that links DAB stations with the Internet. With RadioVIS, radio becomes a richer experience with real time Internet content. It specifies how web information is added to radio function, giving you DAB broadcasts accompanied by vivid slideshows of news, traffic updates, commercials and more, deepening the information radio stations provide. To enjoy RadioVis, simply go to the Apple App Store to download the free Philips DigitalRadio app. The app also hands you full control of all DAB+ and FM radio.

### Play and charge your iPod/iPhone



Enjoy your favourite MP3 music while charging your iPod/iPhone! The dock lets you connect your portable device directly to the Docking entertainment system so you can listen to your favourite music in superb sound. It also charges your iPod/iPhone while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The Docking entertainment system automatically

charges your portable device while it is docked.

### FM digital tuning with presets



Digital FM radio offers you additional music options to your music collection on your Philips audio system. Simply tune into the station that you want to preset, press and hold the preset button to memorise the frequency. With preset radio stations that can be stored, you can quickly access your favourite radio station without having to manually tune the frequencies each time.

### **Bass Reflex Speaker System**



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a

bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep

### **Auto clock synchronisation**



When connected and docked, this docking system will automatically synchronise the clock with your iPod/iPhone within a few seconds. With this convenient feature, you do not need to set the time manually.

### Dock iPod/iPhone in its case

Smartly designed spring-loaded docking port effortlessly accommodates any iPod or iPhone, without special adapters. What's more, it works even when most protective cases are on - just dock your iPod or iPhone as it is. Now you can truly have fuss-free enjoyment of your music.















# **Specifications**

### iPod compatibility

 Compatible with: iPod touch, iPod touch 2nd Generation, iPod classic, iPod nano 3rd Generation, iPod nano 4th Generation, iPod 5th Generation, iPod with colour display, iPod nano, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation

### iPhone compatibility

 Compatible with: iPhone 3G, iPhone 3GS, iPhone 4, iPhone 4S

### iPod/iPhone App

- App name: HomeStudio, Free download from App store
- Compatibility: Dock radio for iPod/iPhone, iPod Touch, iPhone
- 5-day weather forecast
- Playback: album/track navigation, playback controls
- Clock: analogue display, digital display
- Alarm: multiple alarms, sleep timer
- Radio: FM radio, preset, scan, tune

### **Audio Playback**

 Playback mode: Charging iPod, Charging iPhone, Fast forward and reverse, Next and Previous track, Play and Pause

### Tuner/Reception/Transmission

- Tuner bands: DAB (Band III), FM
- Frequency range: (FM) 87.5-108 MHz
- Station presets: 20

- · Auto digital tuning
- DAB: info display, menu, smart scan

### Convenience

- Clock/Version: Digital
- Alarms: Dual alarm time, Buzzer Alarm, Radio Alarm, Repeat alarm (snooze)
- User convenience: Sleep Timer
- Backlight colour: Blue
- Display Type: LCD
- Display Enhancements: Brightness Control

#### Sound

- Sound System: Stereo
- Volume control: rotary (digital)
- Equalizer settings: Classic, Jazz, Pop, Rock
- Output power (RMS): 20 W

### Loudspeakers

• Built-in speakers: 2

#### **Power**

• Mains power: 100-240 V

### **Dimensions**

- Product dimensions (WxDxH): 288 x 118 x 112 mm
- Packaging dimensions (WxDxH): 319 x 180 x 144

#### **Accessories**

 Included accessories: AC-DC Adapter, User Manual, Warranty certificate



Issue date 2013-05-10

Version: 3.0.3

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 87169 EAN: 87 12581 63511 4

www.philips.com