



Philips  
Universal remote control

2in1 for TV/DVD

SRU160NC

## Flat, fun & fast

Universal zapper, for easy TV zapping, DVD playing and AMP volume setting regardless of brand.

### Single control solution for most devices & brands

- Ideal zapper now you can enjoy watching your DVD, so easy!
- Ready for use with Philips equipment

### Great convenience

- Surprisingly flat remote
- Dedicated keys for moving around menus
- Battery low indication shows when to refresh batteries

### Quick and easy set-up

- Automatically searches for your equipment brand
- Batteries are included for unwrap-and-zap
- For questions and assistance call our URC service line
- URC support service via dedicated website

# PHILIPS

# Specifications

## Convenience

- Supported devices: TV, DVD
- TV functions: Program up/down, Volume up/down, mute, Power/standby, 16:9
- DVD functions: Transport keys, System menu control, Disc menu control
- Ease of Installation: Autosearch
- Installation steps: 2
- Language support: GB/F/D/NL/I/E
- Languages in manual: GB/F/E/D/NL/I/P/S/DK/N/ FIN
- Number of keys: 22
- Preprogrammed for Philips
- Regulatory approvals: CE Mark
- Splash proof

## Accessories

- Battery: Yes, CR2025 Coin cell Battery 3V Lithium

## Power

- Battery lifetime: 12 month
- Number of batteries: 1

## Infrared Capabilities

- Operating distance: 7 m
- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: over 600
- Carrier frequency range: 24 - 55 kHz
- Transmission angle: 90 degree

# Highlights

## Home entertainment zapper

With this zapper you can instantly control all the basic functions of your TV and DVD player / recorder, now it's much easier and much more fun to watch a DVD or zap through your TV channels.

## Pre-programmed for Philips

If you have Philips equipment, you can use your universal remote control without programming it because all keys are pre-set for Philips.

## Fun & Flat

Replace a table full of remote controls with a fun zapper that'll operate the basic functions of your TV, DVD and receiver, regardless of the brand or model.

## Dedicated menu keys

Dedicated keys to move easily around your equipment's menus mean simple one finger operation without having to press shift or function shift keys

## Battery-low indication

To know in time when the batteries need to be recharged or replaced.

## Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.



Issue date 2014-02-10

Version: 2.4.8

12 NC: 9082 100 05061  
EAN: 87 10895 90769 9

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)