

Philips
Mini Hi-Fi System

- MP3-CD playback
- USB Direct

FWM185



Listen to your favourite MP3-CD music in rich sound

with USB Direct playback

Experience uninterrupted enjoyment of your CD/MP3/WMA songs for up to 10 hours on the FWM185. Extend your music pleasure by listening to your tunes at home from your portable player — with USB Direct and MP3 player-in.

Enrich your sound experience

- 2-Way Bass Reflex Speaker System for powerful sound
- 120 W RMS total output power

Continuous enjoyment of your favourite music

- 10 hours of MP3-CD music
- AM/FM tuner for radio enjoyment
- Stereo cassette deck
- USB Direct for MP3/WMA music playback
- MP3 player-in for your portable music device

Personalised sound settings

- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimised music style settings

PHILIPS

Highlights

2-Way Bass Reflex System

2-Way Bass Reflex Speaker System for powerful sound

10 hours of MP3-CD music

MP3 stands for "MPEG 1 Audio layer-3".MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the Internet, allowing quick and easy audio file transfer.

AM/FM tuner

AM/FM tuner for radio enjoyment

Stereo cassette deck

Stereo cassette deck

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your

music by precisely adjusting the sound balance to match the type of music you are playing.

120 W RMS

This system has a 120 W RMS total output power. RMS refers to Root Mean Square, which is a typical measurement of audio power, or rather, the electrical power transferred from an audio amplifier to a loudspeaker, which is measured in watts. The amount of electrical power delivered to the loudspeaker and its sensitivity determines the sound power that is generated. The higher the wattage, the better the sound power emitted by the speaker.

USB Direct

With the USB Direct mode, you can simply select the music on a USB device and play back all your content. All you have to do is plug in your USB device to play back music or export content from the device.



Specifications

Sound

- Output power (RMS): 4 x 30 W/ch
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control

Loudspeakers

- Main Speaker: 4" woofer, 2" tweeter, 2-way, Bass Reflex Speaker System
- Number of Loudspeakers: 2

Audio Playback

- Number of Discs: 1
- Loader Type: Tray
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Stop
- Disc Playback Modes: Repeat/one/disc/programme, Shuffle Play, Fast Forward/Reverse, Next/Previous Track Search, Repeat Play
- Programmable Tracks: 20
- Number of decks: 1
- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Automatic Stop

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro-Start

Recording

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW

Convenience

- Alarms: CD Alarm, USB alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Eco Power Standby: 1 watt

Connectivity

- Aux in: 3.5 mm stereo
- USB: USB host

Accessories

- Included accessories: Remote Control, Guarantee booklet, Quick Use Guide
- User Manual: English

Dimensions

- Set dimensions (W x H x D): 220 x 292 x 272 mm
- Packaging dimensions (W x H x D): 525 x 413 x 410 mm
- Weight incl. Packaging: 10.585 kg

Power

- Power supply: 200-240 V, 50 Hz
- Standby power consumption: < 1 W



Issue date 2013-05-10

Version: 6.0.9

12 NC: 8670 000 29047
EAN: 87 12581 32975 4

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com