

Philips 7000 series
Blu-ray Disc player

3D playback

Wi-Fi-Ready Black aluminium

BDP7500B2



Design and performance, purely defined

Revel in the most realistic HD audio ever with this high performance aluminium design and 7.1 audio outputs. Redefine the way you watch Blu-ray movies with CinemaPerfect HD. Be ready for Wi-Fi and enjoy your PC videos via DLNA.

See more

- Fully HD 3D Ready* for a truly immersive 3D movie experience
- CinemaPerfect HD for clearer and sharper video playback
- DivX Plus HD Certified for high-definition DivX playback
- Net TV for popular online services on your TV
- DLNA Network Link to enjoy photos and videos from your PC

Hear more

- Dolby TrueHD and DTS-HD MA for HD 7.1 surround sound
- 7.1 channel surround sound for the best cinematic experience

Engage more

- Hi-Speed USB 2.0 Link plays video/music from USB flash drives
- Built-in 1 GB BD-Live memory for online Blu-ray bonus content
- Touch-sensitive controls for smooth and easy access
- EasyLink to control all HDMI CEC devices via a single remote
- Wi-Fi-n Ready* for faster, wider wireless performance



asimpleswitch.com

PHILIPS

sense and simplicity

Highlights

Fully HD 3D Ready



Be enthralled by 3D movies in your own living room on a Full HD 3D TV. Active 3D uses the latest generation of fast switching displays for real life depth and realism in full 1080 x 1920 HD resolution. When you watch these images through special glasses that are timed to open and close the left and right lenses in synchronisation with the alternating images, the Full HD 3D viewing experience is created. Premium 3D movie releases on Blu-ray offer a wide and high-quality content selection. The Blu-ray 3D feature will be available on this system after software upgrade (visit www.philips.com/blu-ray).

CinemaPerfect HD



Philips' CinemaPerfect HD engine offers a new standard in clear and sharp video playback. This intelligent engine reduces noise and sharpens images to bring you higher quality video images than previously seen. Video noise

reduction and super scaling work to reduce the noise that is produced when video is compressed into MPEG format. With improved colour processing, the engine produces sharp, deep images on screen.

DivX Plus HD Certified



DivX Plus HD offers the latest in DivX technology to let you enjoy HD videos and movies from the Internet direct to your Philips HDTV or PC. DivX Plus HD supports the playback of DivX Plus content (H.264 HD video with high-quality AAC audio in an MKV file container) while also supporting previous versions of DivX video up to 1080p. DivX Plus HD for true HD digital video.

Net TV



Experience a rich selection of online services with Net TV. Enjoy movies, pictures,

infotainment and other online content directly on your TV via the Philips Blu-ray Disc player whenever you like. Simply connect the player directly to your home network through a wired or wireless connection, then navigate and select what you want to watch with the remote control. The Philips menu gives you access to popular Net TV services fitted for your TV screen.

DLNA Network Link



The DLNA Network link provides easy access to personal photos, music, videos or movies on your PC or Home Network. It uses the Ethernet (LAN) connection with DLNA protocol that ensures that DLNA-certified products will work together seamlessly. By connecting your Blu-ray Disc player to your home network, you will be able to access information from all DLNA-certified devices. You can access your world of entertainment at the simple push of a button with the intuitive user interface, which is designed for easy browsing.

Specifications

Picture/Display

- Blu-ray 3D: Full HD 1080p
- Advanced video processing: CinemaPerfect HD
- Picture enhancement: High Def (720p, 1080i, 1080p), Progressive scan, Video upscaling
- Aspect ratio: 21:9, 16:9, 4:3
- D/A converter: 12 bit/150 MHz

Video Playback

- Playback Media: BD Video, BD-R/RE 2.0, DVD, DVD-Video, DVD+R/+RW, DVD-R/-RW, CD, CD-R/CD-RW, USB flash drive, DivX, BD-ROM, Video CD/SVCD
- Compression formats: H.264, VC-1, MPEG2, XviD, DivX Plus™ HD, MKV, AVCHD, WMV
- Disc Playback Modes: Standard Play, Pause, Search forward/reverse, Slow Forward, Resume Playback from Stop, Skip, Disc Menu, Repeat, A-B Repeat, Zoom, Angle
- Video Enhancement: Deep Color, x.v. Colour, Video Upscaling, Progressive Scan
- BD Region Code: B
- DVD Region Code: 2

Sound

- Sound System: DTS-HD Master Audio, Dolby True HD, Dolby Digital Plus, DTS, Dolby Digital
- Signal to noise ratio: 105 dB
- Dynamic Range (1 kHz): 100 dB
- Frequency response: 100 Hz
- D/A converter: 24-bit, 192 kHz

Audio Playback

- Playback Media: CD, CD-R/RW, MP3-CD, MP3-DVD, USB flash drive
- Compression format: DTS, Dolby Digital, AAC (multi-channels), MP3, PCM, WMA

Digital Photo Playback

- Playback Media: USB flash drive, DVD+R/+RW, DVD-R/-RW, CD-R/RW
- Picture Compression Format: JPEG
- Picture Enhancement: High Definition Resolution, Slideshow, Slideshow with MP3 playback, Rotate, Zoom

Connectivity

- Rear Connections: HDMI output, Component

- Video output, Digital optical out, Digital coaxial out, Analogue audio 7.1 channel out, Composite video (CVBS) output, Analogue audio Left/Right out, Ethernet, USB: Philips Wi-Fi adapter only
- Front/Side connections: USB 2.0
- Network connections: Wi-Fi Ready (802.11 g/n)*
- PC network link: DLNA 1.5 certified

Convenience

- Online services: Net TV
- EasyLink (HDMI-CEC): One touch play, One touch standby
- Ease of Use: Touch control buttons
- On-Screen Display languages: English, German, French, Dutch, Italian, Portuguese, Spanish, Danish, Finnish, Polish, Swedish, Turkish, Norwegian, Czech, Russian
- Child Protection: Parental Control
- BD-Live (Internal 1 GB memory)
- Firmware upgradeable: Firmware upgradeable via USB, Online firmware upgrade

Accessories

- Included accessories: Audio/Video cable, User Manual, CD-R (User Manual), Quick start guide, Product Registration Card, Remote Control, 2 x AAA Batteries
- User Manual: English, French, German, Dutch, Italian, Spanish, Portuguese, Danish/Norwegian, Swedish, Finnish, Polish, Turkish, Greek, Russian

Green Specifications

- Certified green product

Power

- Power supply: 220-240 V, 50/60 Hz
- Power consumption: 22 W
- Standby power consumption: 0.25 W

Dimensions

- Packaging dimensions (W x H x D): 509 x 118 x 285 mm
- Weight incl. Packaging: 3.60 kg
- Product dimensions (W x H x D): 435 x 55.7 x 245 mm
- Product weight: 2.85 kg



Issue date 2012-09-03

Version: 3.1.5

12 NC: 8670 000 60567
EAN: 87 12581 52830 0

© 2012 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com

* Philips Wi-Fi USB adapter WUB1110 required (sold separately)
* For more information, visit www.philips.com/blu-ray