

Philips docking speaker

for iPod/iPhone



**DS700** 



# Designed to go places

### Obsessed with sound

Perfect for the iPod nano, this pocket-sized speaker gets rich & powerful music going wherever you are - delivering maximum impact with minimum fuss. Powered by AC or batteries, it plays from all iPod/iPhone, including the new iPod nano.

#### Crystal clear sound

- DBB to preserve low tones for deep bass at any volume level
- Neodymium speakers for pure balanced sound
- Shielding technology to block mobile phone interference

#### Ultra compact and truly portable

- Slim and miniature design for any space, any lifestyle
- Designed fit for iPod nano

#### **Advanced versatility**

- Dock any iPod/iPhone, even in its case
- Battery or AC power option for music enjoyment anywhere
- AUX-in for easy connection to almost any electronic device



### DS700/37

### Specifications

#### iPhone compatibility

• Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

#### iPod compatibility

• Compatible with: iPod, iPod classic, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod nano 5th Generation, iPod nano 6th generation, iPod touch, iPod touch 2nd Generation, iPod touch 2nd Gen 8/16/32GB, iPod with color display, iPod 5th Generation

#### **Audio Playback**

· Cradle playback mode: Charging iPod, Charging iPhone

#### Sound

- · Sound Enhancement: Dynamic Bass Boost
- · Sound System: Stereo
- Volume Control: Volume Control up/down
- Output power (RMS): 4W





#### Loudspeakers

· Neodynium magnet system

#### **Connectivity**

Aux in

#### **Accessories**

· AC/DC Adaptor

#### **Dimensions**

- Packaging dimensions (W x H x D): 304 x 90 x 100 mm
- Product dimensions (WxDxH): 230 x 50 x 65 mm
- Product weight: 0.32 kg
- Weight incl. Packaging: 0.61 kg

#### **Power**

- Power supply: 100-240VAC, 50/60Hz, Battery
- Battery type: AA / LR6 Alkaline
- Number of batteries: 4
- · Operating time on battery: 8 hr

## Highlights

#### **AUX-**in for easy connection

AUX-in for easy connection to almost any electronic

**Battery or AC powered**Battery or AC power option for music enjoyment

#### Designed for iPod nano Designed fit for iPod nano

#### Dock iPod/iPhone in its case



Smartly designed spring-loaded docking port effortlessly accommodates any iPod or iPhone, without special adaptors. What's more, it works even when most protective cases are on - just dock your iPod or iPhone as it is. Now you can truly have fuss-free enjoyment of your music.

#### **Dynamic Bass Boost (DBB)**



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high - at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

#### Slim and miniature design

Slim and miniature design for any space, any lifestyle



Issue date 2014-03-14

Version: 3.0.5

© 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 74882 UPC: 6 09585 21251 0

www.philips.com