

Philips CD Soundmachine

CD, MP3-CD, USB, FM



OS685



The retro boombox

with USB direct

This retro-style boombox not only looks the part but plays music better and louder. Bass reflex technology gives you pumping, deeper bass, and MP3-CD and USB connectivity give all the options you need to bring out the best in your music collection.

Rich and clear sound

- Dynamic Bass Boost for deep and dramatic sound
- 7 W RMS total output power

The ultimate listening experience

- USB Direct for MP3/WMA music playback
- Play MP3/WMA-CD, CD and CD-RW
- FM tuner for radio enjoyment

Easy to use

- 20-track CD programmable
- CD Shuffle/Repeat for personalised music enjoyment
- Audio-in for easy portable music playback



Highlights

Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

USB Direct




With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

20-track CD programmable

The CD programmable playback feature allows you to enjoy your favourite tracks in the order you want.

CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favourite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

Play MP3/WMA-CD, CD and CD-RW



Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio

quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player. Download MP3 or WMA songs from authorised music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.

AUDIO-IN (3.5 mm)



Make one easy connection and enjoy all your music from portable devices and computers. Simply plug your device into the AUDIO-IN (3.5 mm) port on your Philips set. With computers, the connection is typically made from the headset output. Once linked, you can enjoy your entire music collection directly, on a set of superior speakers. Philips simply delivers better sound.

FM tuner

FM tuner for radio enjoyment













Specifications

Audio Playback

- Disc Playback Modes: Fast Forward/Reverse, Next/ Previous Track Search, Programme Play, Repeat Play, Shuffle Play
- Loader Type: Front
 Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Programmable Tracks: 20
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle

Connectivity

- USB: USB host
- Audio in (3.5 mm)

Tuner/Reception/Transmission

- · Antenna: FM antenna
- Tuner bands: FM
- Station presets: 20
- · Tuner enhancement: auto digital tuning

- Output Power: 7 W max.
- Sound System: Stereo
- Speaker diameter: 4"
- Volume control: rotary (digital)
- · Sound enhancement: bass reflex system, Dynamic Bass Boost

Loudspeakers

- Built-in speakers: 2
- Speaker diameter: 4"

Convenience

- Display Type: LED
- Display Enhancements: Brightness Control

Accessories

- · Power cord
- User Manual: English
- Warranty: Warranty leaflet

Power

- Number of batteries: 6 x LR14/C-cell (not included)
- Mains power: 220-240 V 50/60 Hz

Dimensions

- Packaging depth: 146 mm
- · Packaging height: 275 mm
- Packaging width: 510 mm
- Weight incl. Packaging: 3.3 kg
- Weight: 2.3 kg
- Main unit depth: 146 mm
 Main unit height: 275 mm
- Main unit width: 447 mm



Issue date 2014-07-19

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 2.0.3

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 00335 EAN: 08 71258 16780 67

www.philips.com