



Philips Fidelio  
Over-ear wireless  
headphones

Noise Cancellation Pro+  
Natural, balanced sound  
Premium leather design  
38 hours of play time



L3

## Get inside the music. Anywhere.

What if you could always be in the perfect place to listen to the music you love?

Exquisitely tuned drivers, excellent Active Noise Cancelling and the right fit combine to create the perfect listening environment. Wherever you are.

### Detailed sound, no distractions

- Philips Fidelio. Engineered for exceptional performance
- 40 mm drivers. Natural, balanced sound
- State-of-the-art hybrid Active Noise Cancelling

### Quality in every detail

- Crafted for listening. Premium design
- Memory foam ear-cup cushions. Always a perfect fit
- Sumptuous Muirhead leather. Responsibly sourced
- Dual mics for crystal-clear calls. On-board voice control

### Seamless in every way

- Touch controls. 38 hours play time (32 hours with ANC)\*
- IR sensor. Music pauses when you take the headphones off
- Connect to any source. Wireless or wired
- Philips Headphones app. Customise your experience
- One-touch pairing. Google Fast Pair\*

# PHILIPS

## Over-ear wireless headphones

Noise Cancellation Pro+ Natural, balanced sound, Premium leather design, 38 hours of play time

# Highlights

### Philips Fidelio



From the sound to the materials, these over-ear closed-back wireless headphones are crafted to bring you deep into the music. No matter what size or shape your head is, the soft memory-foam ear-cup cushions fit closely and the music pauses if you take the headphones off.

### Natural, balanced sound



The perfectly tuned drivers in these Hi-Res Audio certified headphones deliver beautifully balanced sound - whether ANC is turned on or off. Bass is tight and impactful without being overpowering. Midrange frequencies are full and smooth. High frequencies sparkle with detail.

### Hybrid Active Noise Cancelling



Listen at the perfect volume - wherever you are. Adaptive noise cancelling uses one external mic and one internal mic to filter out

unwanted sounds, leaving you free to immerse. Awareness Mode lets you bring the world back in when you need to.

### Crystal-clear calls



Two mics in each ear cup focus on the sound of your voice, dramatically reducing noise from the world around you. The fully integrated Google Assistant and Alexa are there to help you pull up your favourite playlists as soon as you ask.

### Touch controls



A full charge gives you more than a day of music and a speedy 15 minute charge gives you 6 hours play time. There are touch controls for music and calls and buttons for ANC on the ear cups, which also fold flat for easy storage.

### Crafted for listening



Lightweight aluminium and responsibly sourced Muirhead leather ensure that these

L3/00

wireless headphones feel as premium as the sound. The aluminium of the ear-cup rings is in matte dark satin, with embossed Philips Fidelio branding. The music pauses automatically when you take the headphones off.

### Philips Headphones app.



The Philips Headphones app lets you adjust the level of noise cancellation by switching between preset ANC modes. It also features a dedicated equaliser, and you can use the app to control the music you're streaming or access song information.

### Google Fast Pair\*



## Fast Pair

Google Fast Pair lets you pair your headphones to a compatible Android device with a single tap. When the headphones are placed near your Android device, you are automatically asked if you want to connect.



# Specifications

## Sound

- Impedance: 16 Ohm
- Speaker diameter: 40 mm
- Sensitivity: 103 dB (1k Hz)
- Frequency range: 7 - 40,000 Hz
- Maximum power input: 20 mW
- Hi-Res Audio
- Driver type: Dynamic

## ANC features

- ANC (Active Noise Canceling )
- ANC technology: Hybrid, ANC Pro+
- Awareness mode
- Adaptive ANC
- Microphone for ANC: 4 mic

## Telecommunication

- Microphone for call: 2 mics
- ENC microphone

## Connectivity

- Bluetooth version: 5.1
- Supported codec: AAC, SBC, aptx, aptx-HD
- Maximum range: Up to 10 m
- Bluetooth profiles: A2DP, AVRCP, HFP
- Detachable cable
- Type of wireless transmission: Bluetooth
- Multipoint connection
- Wireless
- Headphone socket: 2.5 mm

## Convenience

- Google Fast Pair
- Auto pause (IR sensor)
- Philips Headphones app support
- Firmware updates possible
- Automatic power off
- Volume control
- Type of controls: Touch

## Design

- Colour: Black
- Wearing style: Headband
- Foldable design: Flat
- Ear fitting: Over-ear
- Earcup type: Closed-back
- Ear coupling material: Synthetic leather

## Power

- Music play time (ANC on): 32 hr\*

- Music play time (ANC off): 38 hr\*
- Battery type (Headphones): Lithium Polymer (built-in)
- Battery capacity (Headphones): 800 mAh
- Talk time: 38 hr
- Charging time: 2 hr
- Fast charging time: 15 mins for 6 hrs
- Number of batteries: 3 pcs
- Battery weight (Total): 10.1 g
- Rechargeable

## Voice assistant

- Voice assistant support
- Voice assistant activation: Manual
- Voice assistant compatible: Apple Siri, Google Assistant

## Accessories

- Audio cable: 2.5-3.5 mm stereo cable, L=1.2 m
- Charging cable: USB-C cable, 500 mm
- Included adapters: Aeroplane adapter
- Others: 1 pcs hard carrying case
- Quick Start Guide

## Product dimensions

- Product dimensions (W x H x D):  
19 x 20.35 x 5.15 cm
- Weight: 0.36 kg

## Packaging dimensions

- Packaging dimensions (W x H x D):  
20.9 x 21.67 x 7.69 cm
- EAN: 48 95229 10839 4
- Number of products included: 1
- Gross weight: 1.068 kg
- Net weight: 0.387 kg
- Tare weight: 0.681 kg
- Packaging type: Box
- Type of shelf placement: Hanging

## Outer Carton

- Number of consumer packages: 3
- Outer carton (L x W x H): 25.4 x 22.8 x 26 cm
- Gross weight: 3.655 kg
- Tare weight: 2.494 kg
- Net weight: 1.161 kg
- GTIN: 1 48 95229 10839 1

## UPC

- UPC: 8 40063 20164 4



Issue date 2023-08-24

Version: 19.6.10

12 NC: 8670 001 66782  
EAN: 48 95229 10839 4

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Google is a trademark of Google LLC. Google Fast Pair is not available in certain languages and countries.

\* Battery life of play time is approximate and may vary depending on application condition.