

Philips
Mini Hi-Fi System

MP3

FWM70



wOOx Technology

Hear the Bass, Feel the Difference!

For those who prize technology and a superb listening experience, simply immerse yourself in the power of wOOx Technology from this mini system. Sit back and enjoy music from your favorite MP3 music in dynamic, rich sounds.

Powerful sound you can hear and feel

- Class 'D' digital amplifier for quality sound performance
- Front firing wOOx Technology speakers
- 2x220W music power

Longer listening, greater enjoyment

- 3-disc changer for convenient multi-disc playback
- 30 hours of MP3-CD music playback
- Dual Logic Tape Deck with auto replay

Ready for gaming

- Gameport connection to your game console
- Game Sound modes for different types of games
- MIX-IT for mixing the game sound with your favorite music

PHILIPS

Highlights

Class 'D' Amplifier

Class 'D' Digital Amplifier takes an analog signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, Class 'D' Digital Amplifier has greater than 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

Front firing wOOx Technology

Front firing wOOx Technology speakers

2x220W music power

2x220W music power

3-disc changer

With a three-disc changer for music playback, you can choose between three different CDs inside the device at any one time. This convenient feature allows you to savor a variety of music while saving you precious time from changing CDs frequently.

30 hours of MP3-CD music

MP3 stands for "MPEG 1 Audio layer-3". MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the

standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

Dual Logic Tape Deck

Dual Logic Tape Deck with auto replay

Gameport connection

Gameport connection to your game console

Game Sound modes

Game Sound modes for different types of games

MIX-IT for mixing game sound

MIX-IT for mixing the game sound with your favorite music



Specifications

Sound

- Output Power: 2 x 220W music power
- Sound Enhancement: Class "D" Digital Amplifier, Incredible Surround, Digital Sound Control, Virtual Ambience Control, wOOx technology, Game Sound, MIX-IT

Loudspeakers

- Main Speaker: 2" tweeter, 3 way, 6.5" woofer, Bass Reflex Speaker System, Piezo, Speaker grilles detachable, wOOx Bass Radiator
- Number of Loudspeakers: 2

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: 99-Track Programmable, Fast Forward/Backward, Next/Previous Track Search, Repeat/one/all/program, Repeat/one/disk/program
- Loader Type: 3 CD Carousel
- Number of Discs: 3
- Cassette Deck Technology: Logic
- Number of decks: 2
- Cassette Playback Modes: Full Auto Stop

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: Automatic Recording Level, CD Synchro Start Recording

Tuner/Reception/Transmission

- Auto digital tuning
- RDS: News, Program Type, Radio Text, RDS Clock Set, Station Name
- Station presets: 40

- Tuner Bands: FM Stereo, MW
- Tuner Enhancements: Auto Store, Easy Set (Plug & Play)

Connectivity

- Aux in: Line in, Gameport
- Headphone: 3.5 mm
- Other connections: Composite video (CVBS) out, FM Antenna, MW Antenna

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: FTD
- Eco Power Standby: 1 watt
- Indications: album name, album number, Cd functions, date, DIM mode, time, track

Accessories

- Included accessories: AC Power Cord, FM/MW Antenna, User Manual
- Remote control: 32-key with 2xAA Batteries

Dimensions

- Main speaker dimensions (W x H x D): 240 x 358 x 230 mm
- Packaging dimensions (W x H x D): 624 x 412 x 510 mm
- Set dimensions (W x H x D): 265 x 322 x 390 mm
- Weight incl. Packaging: 20.5 kg

Power

- Power supply: 200-240 V, 50Hz
- Standby power consumption: < 1W



Issue date 2014-02-10

Version: 7.0.8

12 NC: 9073 100 12285
EAN: 87 10895 86016 1

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com