

Philips  
Portable DVD Player

PET708



## Double your movie enjoyment

with a second TFT LCD screen

Double your entertainment pleasure on the go with the Philips PET708 featuring two 7" TFT LCD display screens! Simply plug in the second screen to share DVD movies or JPEG photos - perfect for in-car enjoyment. Comes with Smart Car Mount.

### Immerse in AV entertainment on the go

- Play DVD, DVD+/-R, DVD+/-RW and (S)VCD discs
- Plays MP3-CD, CD and CD-RW music
- Share JPEG image files with Picture CD

### Comfortable viewing anywhere

- Built-in quality stereo speaker
- 7" TFT colour LCD display for high quality viewing
- Watch movies in 16:9 widescreen format
- Expand movie enjoyment with dual TFT LCD display screens

### For ultimate convenience

- Smart Car Mount for ease-of-use
- Up to 2.5 hours of playback with a rechargeable battery\*
- Share entertainment fun with dual headphone jacks

**PHILIPS**  
sense and simplicity

## Specifications

### Picture/Display

- **Display screen type:** LCD TFT
- **Diagonal screen size (inch):** 7 inch
- **Resolution:** 480(w)x234(H)x3(RGB)
- **LCD panel type:** Anti-glare polarizer
- **Brightness:** 200 cd/m<sup>2</sup>
- **Contrast ratio (typical):** 250:1
- **Effective viewing area:** 154.1x86.6mm
- **Pixel pitch:** 0.107(w)x0.370(H)mm
- **Response time (typical):** 30 ms

### Sound

- **Output Power:** 250mW RMS(built-in speakers)
- **Output power (RMS):** 10mW RMS(earphone)
- **Signal to noise ratio:** >80dB(line out), >76dB(earphone), >62dB(built-in speakers)

### Video Playback

- **Playback Media:** DVD, Picture CD, SVCD, Video CD, DVD-R/+RW, MP3-CD, CD-R/CD-RW, DVD+R/+RW, CD
- **Disc Playback Modes:** A-B Repeat, Angle, Disc Menu, Fast Backward, Fast Forward, OSD, Repeat, Shuffle Play, Slow Backward, Slow Forward, Zoom
- **Video disc playback system:** NTSC, PAL

### Audio Playback

- **Compression format:** Dolby Digital, MP3
- **MP3 bit rates:** 32 - 320 kbps
- **Playback Media:** CD, CD-R, CD-RW, MP3-CD
- **File systems supported:** ISO-9660, Joliet

### Connectivity

- **DC in:** 9~12V
- **AV output:** Composite (CVBS) x1
- **Headphone jack:** 3.5mm Stereo Headphone x 2
- **Audio Output - Digital:** Coaxial (cinch)

### Convenience

- Battery charging indication
- Shock proof

### Accessories

- **AC/DC Adaptor:** AY4130/00 (110-240v, 50/60Hz)
- **Battery pack:** AY4392 (DC 7.4V, Li-ion rechargeable batteries)
- **Cables:** 1 x AV Cables, 1 x Power cable
- **Car kit:** cigarette outlet adaptor, 12vDC
- **Remote control:** RC810(credit card style, 38 keys)
- **User Manual:** English/French/Spanish/Portuguese
- **Power cord:** 1 pcs
- **Second LCD screen:** 7" TFT LCD x 1 pcs
- **Smart car mount:** 2 pcs

### Dimensions

- **Master carton dimensions:** 480 x 280 x 300 mm
- **Master carton quantity:** 3
- **Master carton weight:** 9.1 kg
- **Packaging dimensions (W x H x D):** 285 x 255 x 155 mm
- **Product dimensions (W x H x D):** 202 x 40 x 149 mm
- **Packaging type:** D-box
- **Product weight:** 0.86 kg

## Product highlights

### MP3-CD, CD and CD-RW music

MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A single CD can store up to 10 hours of music.

### Dual TFT LCD display screens

Dual screens allow you to display same videos or images from the portable DVD players. Simply plug in and mount the screens on the headrests in your car. Now you can enjoy your favourite DVD movies and JPEG photos with family and friends at the backseats easily and comfortably.

### Smart Car Mount

To enjoy entertainment on the go, why not bring your portable DVD player from home on the road with you? A unique Car Mount system ensures safety and ease-of-use, with a quick-release arm that facilitates easy removal of the player when not in use. You can bring the portable DVD player with you, leaving just the Mount behind in the car.



Issue date 2009-02-12

Version: 1.0.4

12 NC: 8670 000 33563  
EAN: 87 12581 36124 2

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)