

Philips  
Micro Hi-Fi System



MCM726

## Pure sound in a refined design

with USB Direct playback

Specifically designed for those who truly appreciate the ultimate in style and technology, Philips MCM726 exudes finesse and quality. Enjoy MP3/WMA music from your portable player with USB Direct playback.

### Unlimited listening pleasure

- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW

### Enrich your sound experience

- Incredible Surround™ for enhanced audio enjoyment
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x50W RMS and 2x100W music power

### Start the day your way

- Wake up and sleep timer functions
- Digital tuning with 40 preset stations for extra convenience
- Logic tape deck

### Refined in sound and look

- Elegant wood-finished speakers
- Motorized CD loader for convenience access

# PHILIPS

# Highlights

## USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

## Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo

effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your

music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



# Specifications

## Sound

- Output Power: 2x100 watts music power
- Output power (RMS): 2 x 50 W
- Sound Enhancement: Incredible Surround, Digital Sound Control 4 modes, Dynamic Bass Boost

## Loudspeakers

- Main Speaker: 2 way, Bass Reflex Speaker System, Piezo tweeter, 5.25" woofer, Speaker grilles detachable

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Motorised, Tray
- Cassette Deck Technology: Logic
- Cassette Playback Modes: Electronic Speed Control, Full Auto Stop, Tape Counter
- ID3-tag support
- USB Direct Modes: Play/Pause, Stop, Fast Backward/Fast Forward, Previous/Next, Program Play, Repeat, Shuffle

## Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording, Timer for recording from tuner, Automatic Recording Level

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- RDS: Station Name, Radio Text, RDS Clock Set

- Station presets: 40
- Tuner Enhancements: Auto Store

## Connectivity

- Aux in: 1x(L/R)/ RCA
- Headphone: 3.5 mm
- Other connections: FM Antenna, MW Antenna
- USB: USB host

## Convenience

- Alarms: CD Alarm, Radio Alarm, Tape alarm, Sleep timer
- Clock: On main display
- Eco Power Standby: 1 watt
- Display Type: VFD display

## Accessories

- Included accessories: FM/MW Antenna
- Remote control: 24-key remote with Lithium battery
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- User Manual: 16 languages

## Dimensions

- Set dimensions (W x H x D): 175 x 252 x 360 mm
- Main speaker dimensions (W x H x D): 175 x 252 x 214 mm
- Packaging dimensions (W x H x D): 524 x 353 x 408 mm
- Weight incl. Packaging: 10.67 kg

## Power

- Power supply: 220-240V, 50Hz



Issue date 2014-02-06

Version: 1.1.6

12 NC: 8670 000 28777  
EAN: 87 12581 32773 6

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)