



Philips
Notebook webcam

Easy



SPC230NC

Webcam easy

Plug & play

Webcam easy SPC230 really is so easy. Just plug & play to enjoy video chatting for free using Skype, Windows Live Messenger or other instant messaging services. It's easy on the eye with high-quality resolution and low light enhancement.

High quality photos and video

- 1.3 Mega Pixels resolution (interp.) for extra image quality
- Smooth image with 30 frames per second video
- Low light enhancement mode offers better images in low light
- Rotating body to aim the camera wherever you want

Easy as 1-2-3

- Easy set-up and use
- Standalone external microphone gives you recording freedom
- Compatible with all instant messaging services
- Snapshot button lets you take great instant photos
- Mounts securely on any monitor, laptop or desk



PHILIPS
sense and simplicity

Specifications

Mechanics

- Sensor: VGA CMOS
- Lens maximum aperture: F:2.8
- Lens view angle: 50 degrees
- Lens construction: 1 element
- White balance: 2600 - 7600 K
- Minimum illuminance: < 5 lux
- Data format: RGB
- Colour depth: 24 bit

Resolution

- Video resolution: VGA
- Photo resolution: VGA
- Interpolated video resolution: 1.3 MP
- Interpolated photo resolution: 1.3 MP
- Maximum frame rate: 30 fps

Audio

- Microphone: External microphone

Accessories

- Included accessories: External microphone

Additional features

- Snapshot button
- On/off activity LED

Software

- Add video to: Skype, Windows Live Messenger, Yahoo! Messenger, AOL Instant Messenger

System Requirements

- Operating System: Microsoft Windows XP (SP2), Microsoft Windows Vista



- Processor: Pentium III 500 MHz
- RAM memory: 128 MB RAM
- Hard disk space: 200 MB
- USB: Free USB port
- CD-ROM or DVD-ROM Drive

Connectivity

- Cable length: 1.5 metre
- Interfacing: USB 1.1
- Power: Supplied via USB cable

Packaging dimensions

- Packaging dimensions (W x H x D): 19.2 x 18.7 x 9.4 cm
- Nett weight: 0.082 kg
- Gross weight: 0.357 kg
- Tare weight: 0.275 kg
- EAN: 87 12581 39589 6
- Number of products included: 1
- Packaging type: Carton

Outer Carton

- Outer carton (L x W x H): 40 x 30.1 x 22 cm
- Nett weight: 0.492 kg
- Gross weight: 2.8 kg
- Tare weight: 2.308 kg
- EAN: 87 12581 39590 2
- Number of consumer packagings: 6

Dimensions

- Product dimensions (W x H x D): 35 x 125 x 75 mm
- Product weight (g): 82 g

Highlights

1.3 Mega Pixels (interpolated)

Your webcam gives you 1.3 Mega Pixels (interpolated) for both video and photo resolution. So, you can use it to take high-quality photos that still look great when printed as larger-sized images.

30 frames per second video

Sit back and enjoy superior viewing with 30 frames per second video. This gives you smoother video images and a better all-round video-chatting experience.

Low light enhancement

Low light enhancement improves the brightness of the image under low light conditions.

Rotating body

Enjoy webcamming freedom with a clever rotating body that lets you aim the camera wherever you want. Just twist the camera 360° in any direction to film anywhere in your room without moving the webcam at all.

Easy set-up and use

Setting-up and using your webcam is easy as 1-2-3. 1. Install software 2. Plug in camera 3. Video call instantly

Standalone external microphone

With a separate external microphone, you have the freedom to place it where it best picks up your voice to add high-quality audio to your video chats.

Compatible with all services

The webcam and its software have been designed with all instant messaging services in mind. Add video to Skype, Windows Live Messenger, Yahoo! Messenger, AOL Instant Messenger and other services.

Snapshot button

With just one press of this button, your webcam takes a picture automatically. It's a fun way to share your pictures by adding them to e-mails, web pages or documents.

Mounts securely

The multifunctional stand makes it easy for you to mount the webcam securely on top of any monitor, laptop or desk. This design is especially secure and won't move or fall when you're in the middle of a conversation.



Issue date 2013-02-01

Version: 6.0.5

12 NC: 8670 000 37143
EAN: 87 12581 39589 6

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com