

# Portable

## Small & lightweight

Delight your friends by sharing your music with these handy, powerful & compact speakers. Take them anywhere to plug & play with your MP3, your CD player or your laptop.

#### For superb music pleasure

- · Powerful speaker drivers for ultra realistic sound
- Bass pipe emphasizes low tones for a clear, realistic sound
- Wide stereo sound stage when speakers placed apart.

### Share your music anywhere

- Small and lightweight for carrying in your pocket or bag
- Universal use with all portable entertainment equipment

#### Always ready to go

- No batteries required for extra convenience
- Plug & play with all portable music devices



### SBP1100







## Specifications

#### Sound

• Frequency response: 100 - 18 000 Hz

· Impedance: 8 ohm

• RMS Power rating: 2 x 1 W

• Speaker diameter: 50mm

#### **Connectivity**

• Cable length: 1.2 m

• Connector: 3.5 mm stereo

· Finishing of connector: Chrome plated

#### Convenience

· Operating time: No Batteries Required

#### Accessories

AC/DC Adaptor: No

· Adaptor type: N/A

· Battery voltage: 0 V

• Number of batteries: 0

#### **Packaging dimensions**

• Packaging dimensions (W x H x D):  $6.1 \times 5.9 \times 3.9$  inch

· Gross weight: .915 lb • Nett weight: .683 lb

· Tare weight: .232 lb

#### **Outer Carton**

• Gross weight: 26.878 lb

Outer carton (L x W x H): 25 x 13.1 x 14.5 inch

• Nett weight: 16.402 lb · Tare weight: 10.476 lb

### **Inner Carton**

• Gross weight: 6.135 lb

Inner carton (L x W x H): 12.6 x 11.9 x 6.6 inch

• Nett weight: 4.101 lb · Tare weight: 2.034 lb

## Highlights

#### Powerful speaker drivers

Powerful speaker drivers produce ultra realistic sound, totally immersing you in the game.

Thanks to an acoustically-tuned air channel that turbocharges the bass notes, you enjoy fantastic realism and a truly involved listening experience.

#### Wide stereo soundstage

These portable speakers create a natural stereo sound stage when they are a placed apart, this gives the impression that each musical instrument occupies a different physical space. The effect is more realistic and more enjoyable.

#### Compact and lightweight

Small and lightweight you'll hardly notice it's with you. Pop it in your pocket or bag and take it anywhere.

#### For portable equipment

Universal use with all portable entertainment equipment. Simply connect using the 3.5mm plug.

#### No batteries required

For extra convenience, no batteries are required in these portable speakers. They are powered by the portable audio player's ouyput signal.

Plug & play speakers
The 'plug & play' feature saves you time because you simply connect the speakers to the portable audio player as you would normally connect the headphones, by using the jack plug.



Issue date 2010-12-08

Version: 3.0.4

© 2010 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 9082 100 05711 UPC: 0 26616 02878 8

www.philips.com