



Philips  
CD Soundmachine with  
Dynamic Bass Boost

PSS010

## Sound Takes Shape

Sound takes shape and adds a new dimension to your audio experience. Intrigued by unique design and inspiring innovation, you'll be wowed by unexpected big sound from this small yet potent marvel, which complements your personal space.

### **A new dimension to your audio experience**

- Unique and innovative, 'soft' design
- Small footprint to blend into any lifestyle
- Sophisticated aluminum body

### **Unexpected power**

- Built-in speakers featuring XSL Acoustics for dynamic sound
- Dynamic Bass Boost for deep and dramatic sound

### **Easy to use**

- Touch Screen for easy navigation
- Digital tuning with presets
- Motorized CD loader for convenience access
- Handy remote control

**PHILIPS**  
sense and simplicity

# Specifications

## Sound

- Front Speakers Ways: 2
- Loudspeaker Enhancement: Detachable Cloth Grilles
- Loudspeaker types: Bass Reflex Speaker System
- Magnet type: Neodymium
- Output power (RMS): 2X2W+4W
- Sound Enhancement: Advanced Sound System, Dynamic Bass Boost
- Sound System: Stereo
- Volume Control: digital
- Woofer: 1 inch

## Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Motorised
- Programmable Tracks: 20

## Tuner/Reception/Transmission

- Antenna: FM Antenna
- Antenna location: External
- Auto digital tuning
- Tuner Bands: FM



## Connectivity

- DC in: 10V
- Headphone: 3.5 mm

## Convenience

- Backlight
- Backlight color: Blue
- Clock/Version: Digital
- Display Digits: 7
- Display Enhancements: Brightness Control, Function indication, Touch screen control
- Display Type: LCD

## Accessories

- AC/DC Adaptor
- Included Accessories: User Manual, Warranty certificate
- Remote control: 17 Key

## Dimensions

- Packaging dimensions (W x H x D): 413 x 278 x 313 mm
- Product dimensions (W x H x D): 213 x 178 x 213 mm
- Weight: 3.4 kg
- Weight incl. Packaging: 4.4 kg

## Power

- Adaptor type: 10V 1200mA

# Highlights

## Unique and innovative design

Unique and innovative, 'soft' design

## Small footprint

Small footprint to blend into any lifestyle

## Sophisticated aluminum body

Sophisticated aluminum body

## XSL Acoustics

Enjoy dynamic sound and powerful bass performance from your ShoqBox with XSL Acoustics. Impressive sound is produced by combining bright, brisk treble and mid range sound with elastic, powerful bass. Innovative use of high-tech materials like titanium cone and neodymium magnet deliver sound output that's nearly double the power of a traditional speaker driver of the same size. Precise tuning between the speaker driver, the small acoustic architecture and the circuitry ensures superbly dynamic sound and optimizes bass performance from the smallest sound enclosure.

## Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Touch Screen

Touch Screen Control allows you to control your device by simply pressing on-screen buttons rather than physical buttons on the device. Simply power up the device and the touch screen user interface will show up on the LCD display with all the control options for the device. Touch Screen Control combines LCD display technology with pressure sensors and a powerful digital micro processor. When you press on a specific area of the screen with your finger, the relevant signal is sent to the processor and the command is immediately executed.

## Digital tuning with presets

Digital tuning with presets

## Motorized CD loader

Motorized CD loader for convenience access

## Handy remote control

Handy remote control



Issue date 2009-08-09

Version: 4.0.5

12 NC: 9073 101 01304  
EAN: 87 10895 82168 1

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)