



Philips  
Wireless headphones

6mm drivers/ closed-back  
Bluetooth®  
Black



TAUT102BK

## Made for you

Rock your sounds in comfort. These in-ear headphones offer true wireless freedom and a small earphone design that fits securely. You get up to 12 hours play time with the small charging case that slips neatly into pockets and bags.

### **Ready to go. Up to 12 hours play time.**

- Small charging case. Multiple charges in your pocket.
- 6 mm neodymium acoustic drivers. Great sound, punchy bass.
- Get up to 12 hours play time with the charging case
- Mono mode for when you want to leave one ear free

### **Small. Snug. Colorful.**

- Small earphone design.
- Secure, comfortable fit. No need for wingtips.
- Oval acoustic tube. Comfort and passive noise isolation
- Three sizes of ear-tip cover-for a perfectly secure fit.
- Five matte colorways.

### **Easy pairing. Voice control.**

- Noise and echo cancellation for clear voice
- Smart pairing. Automatically find your Bluetooth device
- Multi-function button. Easily control music and calls

# PHILIPS

Wireless headphones  
6mm drivers/ closed-back Bluetooth®, Black

# Specifications

## Connectivity

- Bluetooth profiles: A2DP, HFP, AVRCP
- Bluetooth version: 5.0
- Supported codec: SBC
- Maximum range: Up to 10 m

## Accessories

- Quick Start Guide
- Ear caps: 3 sizes (S/M/L)
- Charging cable: Micro USB cable

## Convenience

- Call Management: Answer/End Call, Call on Hold, Reject Call, Switch between 2 calls

## Power

- Battery type: Lithium-Ion
- Music play time: 3+9 hr
- Standby time: 50hr
- Talk time: 2.5hr
- Rechargeable
- Charging time: 2 hr

## Sound

- Diaphragm: PET
- Frequency response: 20 - 20 000 Hz
- Magnet type: NdFeB
- Impedance: 16 Ohm
- Speaker diameter: 6mm

## Inner Carton

- Gross weight: 0.32 kg
- GTIN: 2 08 40063 20049 8
- Inner carton (L x W x H): 19 x 11 x 11.5 cm
- Nett weight: 0.159 kg
- Number of consumer packagings: 3
- Tare weight: 0.161 kg

## Outer Carton

- Gross weight: 2.95 kg
- GTIN: 1 08 40063 20049 1
- Outer carton (L x W x H): 40 x 24 x 24.5 cm
- Nett weight: 1.272 kg
- Number of consumer packagings: 24
- Tare weight: 1.678 kg

## Packaging dimensions

- Packaging dimensions (W x H x D): 9.5 x 17 x 3 cm
- Gross weight: 0.085 kg
- Nett weight: 0.053 kg
- Tare weight: 0.032 kg
- UPC: 8 40063 20049 4

## Product dimensions

- Product dimensions (W x H x D): 5.3 x 2.7 x 3.57 cm
- Weight: 0.0296 kg

## Design

- Color: Black

TAUT102BK/27

# Highlights

## Up to 12 hours play time.

You get up to 3 hours play time on a single charge. If you head out with a fully charged case, you get an additional 9 hours over multiple charges. Just pop the headphones back in the case each time they need charging. A full charge takes 2 hours.

## 3 sizes of ear-tip.

Interchangeable rubber ear-tip covers let you find the perfect in-ear fit-creating a tight seal so you won't miss a beat.

## 6 mm neodymium driver.

The 6 mm neodymium acoustic drivers give you great sound and punchy bass.

## Multi-function button.

Easily control music and calls via the multi-function button. Don't like the current track. Skip it with a long press. Want to reject a call and keep listening. A simple button-press takes care of that.

## Noise and echo cancellation

The built-in mic with noise and echo cancellation keeps sound clear when you take a call.

## Hey Siri! Hey Google!

Wake your phone's voice assistant with a double button-press. Ask Siri or Google Assistant to play some music, call or send messages to friends, check the weather, and more.

## Smart Bluetooth pairing

Your headphones are ready to pair the instant you take them out of the case. Once they're paired, the headphones remember the last device they were paired with.

## Small charging case.

With their ultra-portable charging case, these headphones won't let you down.

## Small earphone design.

You can rock your sounds in real comfort thanks to the snug-fitting, lightweight design.



Issue date 2022-11-10

Version: 6.0.1

12 NC: 8670 001 63806  
UPC: 8 40063 20049 4

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)