

Philips
DVD/SACD Player

DivX playback

DVP5505S



See, hear, play everything

Be impressed with this Philips DVD/SACD player. It gives you the wonder of multi-channel Super Audio CD music and surround sound cinematic movie experience. Immerse yourself in your personal entertainment.

Unrivalled video performance

- PAL & NTSC Progressive Scan gives razor-sharp images
- RGB on Scart single connection for high-quality video
- 108MHz/12 bit video processing high-resolution images

Pure multi-channel sound

- Multi-channel Super Audio CD for total music immersion
- 192kHz/24 bit audio DAC enhances analogue sound input
- Built-in decoders for Dolby Digital and DTS

Play it all

- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD, DivX
- Music: SACD, CD, MP3-CD, CD-R, CD-RW & Windows Media™ Audio
- Picture CD (JPEG) with music (MP3) playback

PHILIPS

Highlights

PAL & NTSC Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending fields with the odd lines to the screen first, followed by the fields with the even lines, both fields are written at one time. A flicker-free high resolution image is created giving you the best viewing experience.

RGB on Scart connectivity

RGB on Scart is a cable connection that provides easy connectivity for high quality video output.

108MHz/12 bit video processing

Video Upsampling is a technology that decreases distortion to dramatically improve picture quality. It is a technology that allows the normal 13.5MHz video signal to be up sampled to 8 times the frequency.

Multi-channel Super Audio CD

Multi-channel SACD is a new generation music format that offers ultra high quality music reproduction. With a 5.1 multi-channel surround sound and full CD compatibility both forward and backward, what results is unsurpassed audio performance for your listening pleasure.

192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

Built-in DD and DTS decoders

A Built-in Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an

astoundingly natural sense of ambience and dynamic realism.

Multi-format Movies with DivX

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

Music:SACDWindows Media™ Audio

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

Picture CD with MP3 Playback

Picture CD is a CD-R or CD-RW disc on which you can store your MP3 and digital pictures. When inserting a Picture CD in the DVD player, a screen menu will pop up, showing your JPEG's and/or MP3 files on the disc. Just select the music and pictures files you wish to enjoy and press play or OK. You can watch your pictures on TV with your music playing simultaneously.



Specifications

Picture/Display

- Aspect ratio: 4:3, 16:9
- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Smart Picture Setting

Sound

- D/A converter: 192kHz/24-bit
- Signal to noise ratio: 100 dB
- Distortion and Noise (1kHz): 85 dB
- Crosstalk (1kHz): 100 dB
- Dynamic Range (1kHz): 90 dB
- Sound System: Dolby Digital, Dolby Prologic II, DTS
- Sound Enhancement: 3D Virtual Surround, Night Mode, Smart Sound

Video Playback

- Playback Media: CD, CD-R, CD-R/CD-RW, Video CD/SVCD, DVD+R, DVD+RW, DVD-R, DVD-RW (Video mode), DVD-Video
- Compression formats: MPEG1, MPEG2, MPEG4, DivX 3.11, DivX 4.x, DivX 5.x, XviD
- Video disc playback system: NTSC, PAL

Audio Playback

- Compression format: PCM, MP3, Windows Media™ Audio
- Playback Media: CD, CD-R, CD-RW, MP3-CD, SACD Stereo, SACD Multichannel
- MP3 bit rates: 32 - 256 kbps

Still Picture Playback

- Playback Media: DVD+R/+RW, Picture CD

- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Zoom, Slideshow with MP3 playback

Connectivity

- Other connections: Scart, ComponentVideo out, Progressive, Composite video (CVBS) out, Analog audio Multi-channel, Digital coaxial out

Convenience

- Child Protection: Parental Control, Child Lock
- On-Screen Display languages: Danish, Dutch, English, Finnish, French, German, Italian, Norwegian, Portuguese, Spanish, Swedish, Turkish, Polish

Power

- Power supply: 50Hz, 220-240V
- Power consumption: 10 W
- Standby power consumption: < 0.8 W

Accessories

- Batteries: 2 x AA
- Cables: None
- Remote control: 3139 258 70081
- Warranty Card
- User Manual: English, German, Polish, Russian

Dimensions

- Set dimensions (W x H x D): 435 x 37 x 265 mm
- Set weight: 2.17 kg
- Packaging dimensions (W x H x D): 490 x 82 x 352 mm
- Weight incl. Packaging: 3.45 kg



Issue date 2014-02-10

Version: 9.0.10

12 NC: 8622 810 12187
EAN: 87 10895 85777 2

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com