



Philips
Digital PhotoFrame

7"

Multimedia 4:3 frame ratio

SPF2007



"...you really shouldn't have!"

Relive those unforgettable faces and moments with this PhotoFrame. This frame is designed for ease of use as well as being eco-friendly. Rest assured that while you are enjoying your photos, you have made the right choice for the environment.

Top quality display for amazing viewing experience

- imagen Pro for sharper and vibrant colours
- 4:3 aspect ratio for optimal distortion-free display
- Add new glow to old memories with RadiantColor

Simple intuitive operation and great convenience

- Automatic slideshow from USB or memory card
- Auto photo orientation to fit portrait or landscape modes
- Have fun with collages: display multiple photos in one view

Environmentally friendly green design

- Eco-friendly Photoframe
- Auto turning display on/off at pre-set times for power saving

PHILIPS
sense and simplicity

Specifications

Picture/Display

- Viewing angle: @ C/R > 10, 120° (H)/100° (V)
- Lifetime, to 50% brightness: 20,000 hr
- Aspect ratio: 4:3
- Panel resolution: 800 x 600
- Brightness: 250 cd/m²
- Contrast ratio (typical): 300:1

Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

Storage Media

- USB: USB flash drive
- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo (via adapter), MS Pro Duo (via adapter)
- Built-in memory capacity: 512 MB (for 500 HD photos)

Convenience

- Card Reader: Built in (2 x)
- Photo format supported: Up to 10 MB JPEG files, Up to 20 Megapixels, JPEG photo
- Video format supported: MotionJPEG, .AVI
- Background Music supported: MP3
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Album management: Create, Delete, Edit, Rename
- Photo edit: Copy, Delete, Rotate, Zoom and crop
- Slideshow setting: Random, Sequential, Transition effect, Collage (multiple pictures)
- Setup function: Brightness adjustment, Language, Slideshow, Status, Auto on/off, Beep on/off, Set time and date, Photo source, Clock display enable/disable, Event reminder with snooze
- System status: Firmware version, Remaining memory
- Connected media status: Connected media, Remaining memory
- Regulatory approvals: CE, GOST, Switzerland, C-Tick
- Placement: Photo auto orientation, Landscape, Portrait
- On-Screen Display languages: English, Spanish, German, French, Italian, Dutch, Danish, Portuguese, Russian, Simplified Chinese
- Photo effects: Black and White, Sepia
- Plug and Play Compatibility: Windows Vista, Windows 2000/XP or later, Mac OS X

- Screen background: Black, White, Grey, Auto-fit
- Other convenience: Kensington lock compatible

Accessories

- Included accessories: AC-DC Adapter, Quick start guide, USB cable, User manual on CD-ROM
- User Manual: Arabic, Czech, Danish/Norwegian, Dutch, English, Finnish, French, German, Greek, Italian, Malay, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Traditional Chinese, Turkish

Dimensions

- Set dimensions with stand (W x H x D): 206.4 x 139.3 x 103 mm
- Weight: 0.345 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -20°C to 70°C

Power

- Power supply: 100-240 VAC, 50/60 Hz
- DC output Volt: 9 V
- DC output Ampere: 1 A
- Power consumption: (System on) 5.6 W
- Power mode supported: AC powered

Packaging dimensions

- Packaging dimensions (W x H x D): 22.5 x 19 x 9 cm
- Net weight: 0.6 kg
- Gross weight: 0.95 kg
- Tare weight: 0.35 kg
- EAN: 87 12581 49571 8
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 8.9 x 7.5 x 3.5 inch
- Gross weight: 2.094 lb
- Net weight: 1.323 lb
- Tare weight: 0.772 lb

Outer Carton

- Outer carton (L x W x H): 23.4 x 19 x 19.8 cm
- Net weight: 1.2 kg
- Gross weight: 2.1 kg
- Tare weight: 0.9 kg
- GTIN: 1 87 12581 49571 5
- Number of consumer packages: 2
- Gross weight: 4.630 lb
- Outer carton (L x W x H): 9.2 x 7.5 x 7.8 inch
- Net weight: 2.646 lb
- Tare weight: 1.984 lb

Highlights

imagen Pro

The unique Philips imagen enhancement technology automatically analyses your photos to correct colour and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more colour accuracy, colour depth and smart contrast. On top of these, imagen Pro offers enhanced skin colour, sharper images and flicker-free photo viewing which is very important for still pictures.

4:3 perfect frame ratio

Philips digital PhotoFrame ensures your photo is displayed in 4:3 ratio for the best viewing experience.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the colour on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

Automatic slideshow

Automatic slideshows start from any USB drive or memory card for all those times you don't want to spend time copying photos to your PhotoFrame.

Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognises PhotoFrame orientation and displays each photo in its proper mode.

Multiple-photo collage effect

It's a slideshow effect to show photos in collage form, which automatically and randomly compiles different photos together, eliminating unattractive borders that may result from photos that are smaller than the screen size.

Eco-friendly Photoframe

Philips PhotoFrames are designed and produced according to our EcoDesign principles aimed at minimising overall environmental impact through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability.

SmartPower

A timer turns PhotoFrame on and off at the times you choose, reducing energy consumption for the sake of our environment and saving up to one third of your PhotoFrame energy costs.



Issue date 2010-01-29

Version: 3.3.2

12 NC: 8670 000 55182
EAN: 87 12581 49571 8

© 2010 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com