



Philips  
Wireless hi-fi headphones

Adjustable fit  
Infrared transmission

SHC2000



## IR wireless

For TV

These full-size rechargeable infrared cordless headphones combine quality and convenience for either TV or music enjoyment in your home.

### **You'll forget you're wearing them!**

- Lightweight design improves comfort for prolonged use.
- Self adjusting inner headband ensures a comfortable fit

### **The perfect wireless listening experience**

- High-frequency RF ensures clear and sharp reception
- ALC helps prevent audible distortion of input signals

### **Always ready to go**

- IR wireless transmission provides freedom of movement
- Reduces costs by using rechargeable batteries

# PHILIPS

Wireless hi-fi headphones  
Adjustable fit Infrared transmission

# Specifications

## Sound

- Acoustic system: closed
- Magnet type: Ferrite
- Frequency response: 18 - 20 000 Hz
- Sensitivity: 108 dB
- Speaker diameter: 32 mm

## Tuner/Reception/Transmission

- Effective range: 7 m
- Carrier frequency range: 2.3 (L) - 2.8 (R) MHz
- Channel separation: >30 dB
- Modulation: FM

## Convenience

- Operating time: +/- 15 hours

## Power

- Power supply headphone: 2 x 1.5 V NiMH R03/AAA
- Power supply transmitter: AC/DC adapter 12V/

200mA

## Inner Carton

- Gross weight: 5.0852 kg
- Inner carton (L x W x H): 42.9 x 30.6 x 24.2 cm
- Nett weight: 3.666 kg
- Tare weight: 1.4192 kg

## Outer Carton

- Gross weight: 11.0365 kg
- Outer carton (L x W x H): 44.5 x 32.3 x 51.5 cm
- Nett weight: 7.332 kg
- Tare weight: 3.7045 kg

## Packaging dimensions

- Packaging dimensions (W x H x D): 20.7 x 10 x 22.5 cm
- Gross weight: .7867 kg
- Nett weight: .611 kg
- Tare weight: .1757 kg

SHC2000/00

# Highlights

## Lightweight design



The durable, lightweight quality materials enhance comfort for extended wearing.

## Self adjusting inner headband

The inner headband makes it easy to obtain a perfect fit for your head. The mechanism adjusts automatically for comfort.

## High-frequency modulation

Using very high frequency modulation(RF) for the transmission link ensures sharp clear reception.

## Automatic Level Control (ALC)

This smart electronic circuit ensures that the audio input level is automatically adjusted to the right level, preventing distortion and preserving your listening enjoyment.

## IR wireless transmission

IR wireless transmission allows you to be free from the hassles of cables.

## Rechargeable system

The headphone set incorporates facilities for recharging the batteries.



Issue date 2014-03-10

Version: 5.0.7

12 NC: 9082 100 07812  
EAN: 87 10895 95765 6

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)