



Philips SoundBar
Home theatre

300 W RMS power

SoundBar

HSB2313

Complete your HD TV experience

with a powerful subwoofer

Bring your movies and games to life with great surround sound. With 300w of sound power, Integrated HDMI hub and subwoofer, you can now enjoy them in high quality sound and picture, without the clutter!

Great listening experience

- Dolby Virtual Speaker for realistic surround sound
- Subwoofer for powerful bass

HD cinematic viewing experience

- Integrated HDMI Hub connects devices to the TV conveniently

Connect and enjoy all your entertainment

- 300 W RMS total output power
- EasyLink controls all EasyLink products with a single remote
- MP3 Link plays music from portable media players
- USB Link plays photos and music from USB flash drives

Designed to enhance your living space

- Flexible placement on the wall or tabletop
- SoundBar design with optimal fit for 32" flat TV or larger

PHILIPS

Specifications

Accessories

- Included accessories: Remote Control, User Manual, Wall mounting bracket, Batteries for remote control, Power cord, Quick start guide

Audio Playback

- Playback Media: USB flash drive
- MP3 bit rates: 32-256 kbps and VBR

Connectivity

- Front/Side connections: Audio L/R in, CVBS in, USB, MP3 Line-in
- Rear Connections: Composite video (CVBS) output, Digital coaxial in 2 x, Analogue audio Left/Right in 2 x, Component Video output, Composite video (CVBS) input, HDMI in 2 x, HDMI output
- AV 1: Audio L/R in, CVBS in
- AV 2: Audio L/R in, CVBS in
- Subwoofer (Power Box): Interconnect (to Main Unit)

Dimensions

- Set dimensions with stand (H x D): 91.5 x 104 mm
- Set Width: 800 mm
- Subwoofer dimensions (W x H x D): 170 x 330 x 340 mm

Loudspeakers

- Subwoofer type: Active
- Speaker Impedance: 6 ohm
- Subwoofer driver: 1 x 6.5" Long Throw woofer
- Subwoofer freq range: 35-200 Hz
- Subwoofer impedance: 4 ohm

Outer Carton

- EAN: 87 12581 48006 6
- Gross weight: 9.5 kg
- Outer carton (L x W x H): 39.7 x 37.5 x 35 cm
- Net weight: 8 kg
- Number of consumer packages: 1
- Tare weight: 1.5 kg

Packaging dimensions

- Packaging dimensions (W x H x D): 39.7 x 37.5 x 35 cm
- EAN: 87 12581 48006 6
- Gross weight: 9.5 kg
- Net weight: 8 kg
- Number of products included: 1
- Packaging type: Carton
- Tare weight: 1.5 kg

Power

- Power supply: 220-240 V, 50 Hz

Sound

- Output power (RMS): Total 300 W RMS
- Sound System: Dolby Prologic II, Dolby Virtual speaker, Dolby Digital, Stereo
- Equalizer settings: Action, Classic, Concert, Drama, Gaming, Jazz, News, Party, Rock, Sports

Sound Enhancement

- Game mode: Arcade, Racing, Shooting, Sport
- Movie mode: Action, Concert, Drama, Science Fiction

Highlights

Dolby Virtual Speaker

Dolby Virtual Speaker is a sophisticated audio virtualisation technology that produces rich and immersive surround sound from a two-speaker system. Highly advanced spatial algorithms faithfully replicate the sonic characteristics that occur in an ideal 5.1-channel environment. DVD playback is enhanced by expanding the 2-channel environment. When combined with Dolby Pro Logic II processing, any high-quality stereo source is transformed into true-to-life, multi-channel surround sound. No need to purchase extra speakers, wires or speaker stands to appreciate room-filling sound.

EasyLink

EasyLink lets you control multiple devices with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC-enabled equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

USB Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. With USB Link, all you have to do is plug in your USB device, select the photo or music, and play away.

Integrated HDMI Hub

The HDMI Hub gives you the ease of connecting all your devices to the TV without too many wires. It provides you the convenience of enjoying the best possible sound quality while watching different content on your flat TV. You can connect all your HDMI devices directly into the home theatre system's HDMI hub and using only one cable to connect to your flat TV. With this setup, you can easily enjoy your movies or TV programmes in HD picture and sound and not have to deal with messy wires!



Issue date 2015-02-09

Version: 4.0.6

12 NC: 8670 000 52062
EAN: 87 12581 48006 6

© 2015 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com