



Philips
Headphones with mic

14.8-mm drivers/open-back
Ear bud



SHE3015PH



Extra bass

Soft body for comfy fit

Philips SHE3015 headphones with soft body earbuds offer a comfortable fit. Available in eye-catching colours. The built-in mic and control make hands-free talking on mobile easy.

Enjoy quality sound

- 14.8-mm (0.6") speaker drivers for high quality sound
- Neodymium magnets enhance bass performance and sensitivity

Ultimate wearing comfort

- Soft body ensures a comfortable fit
- Rubberised front caps for wearing comfort

Design for convenience

- Flexi-Grip design for durability
- Built-in microphone switches you from music to phone calls

PHILIPS

Headphones with mic
14.8-mm drivers/open-back Ear bud

Specifications

Design

- Colour: Pink

Sound

- Acoustic system: open
- Magnet type: Neodymium
- Voice coil: copper
- Diaphragm: PET
- Impedance: 16 ohm
- Maximum power input: 25 mW
- Sensitivity: 107 dB
- Speaker diameter: 14.8 mm
- Type: Dynamic
- Frequency response: 9 - 22 000 Hz

Connectivity

- Cable Connection: two-parallel, symmetric
- Cable length: 1 m
- Connector: 3.5 mm
- Finishing of connector: nickel plated
- Type of cable: copper

Packaging dimensions

- EAN: 69 23410 73228 3
- Packaging dimensions (W x H x D):
5.2 x 17.5 x 2.8 cm
- Gross weight: 0,0339 kg

- Net weight: 0.0134 kg
- Number of products included: 1
- Packaging type: Soother
- Tare weight: 0,0205 kg
- Type of shelf placement: Soother

Inner Carton

- Gross weight: 0,1287 kg
- GTIN: 2 69 23410 73228 7
- Inner carton (L x W x H): 17.9 x 8 x 6 cm
- Net weight: 0.0402 kg
- Number of consumer packages: 3
- Tare weight: 0,0885 kg

Outer Carton

- Gross weight: 1,2586 kg
- GTIN: 1 69 23410 73228 0
- Outer carton (L x W x H): 34.5 x 19.7 x 16.3 cm
- Net weight: 0.3216 kg
- Number of consumer packages: 24
- Tare weight: 0,9370 kg

Product dimensions

- Product dimensions (W x H x D):
1.6 x 2.1 x 1.25 cm
- Weight: 0.0134 kg

SHE3015PH/00

Highlights

14.8-mm (0.6") speakers

Large 14.8-mm (0.6") speaker drivers squeezed into earbud headphones deliver high quality sound.

Flexi-Grip

A soft, flexible part protects the cable connection from damage that otherwise would occur due to repeated bending.

Neodymium magnets

Neodymium is the best material for producing a strong magnetic field for greater sensitivity in a voice coil, better bass response and higher overall sound quality.

Rubberised front cap

A rubberised front cap provide a totally soft body for wearing comfort.

Soft body

The transparent, rubberised headphone body moulds itself to the shape of the ear for comfortable listening.

Built-in microphone

The built-in microphone lets you switch from listening to music to taking phone calls - easily, so you'll always stay connected with what matters most to you.



Issue date 2016-11-16

Version: 1.2.4

12 NC: 8670 001 17191
EAN: 06 92341 07322 83

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com