

Philips
Classic micro music system

• 30 W

MCM305



Obsessed with sound

Relax with great music

Good sound is yours to have with the Philips classic micro music system. Playback your favourite MP3/WMA music using the USB Direct or MP3 link. Elegantly designed with wood-finished speakers for a classic look that won't go out of style.

Unlimited listening pleasure

- USB Direct for MP3/WMA music playback
- Play MP3/WMA-CD, CD and CD-RW
- MP3 Link for portable music playback

Enrich your sound experience

- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2 x 15 W RMS/2 x 30 W music power

Easy to use

- Motorised CD loader for convenient access
- Wake-up and sleep timer functions
- Radio Data System for station information and data services

PHILIPS

Highlights

USB Direct

With the USB Direct mode, you can simply select the music on a USB device and play back all your content. All you have to do is plug in your USB device to play back music or export content from the device.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do

is to plug your portable MP3 player into the audio system.

Radio Data System (RDS)

The Radio Data System (RDS) lets you tune into radio stations without having to remember the frequencies. In standard mode, RDS displays the station name instead of the transmission frequency, facilitating quick and easy tuning. RDS also allows stations to send text messages such as news and station information directly to the radio display. Commonly used in Europe, RDS text is sent out on the same frequency the radio station broadcasts on. You can choose either the basic RDS display (station name) or subscribe to additional text-based services.



Specifications

Sound

- Sound enhancement: digital sound control 4 modes, Dynamic Bass Boost
- Output power: 2 x 15 W RMS / 2 x 30 W music power

Loudspeakers

- Speaker drivers: 4" woofer, full range
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD, USB flash drive
- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
- Others: ID3-tag support
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, programme play, repeat, shuffle, stop

Tuner/Reception/Transmission

- Tuner bands: FM stereo, MW
- RDS: station name, radio text, RDS clock set, programme type
- Station presets: 30
- Antenna: FM fixed pigtail antenna, MW antenna
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: Headphone (3.5 mm)
- MP3 Link: 3.5 mm stereo line in
- USB: USB host

Convenience

- Alarms: CD alarm, radio alarm, USB alarm
- Clock: on main display, sleep timer
- Loader type: motorised, tray
- Display type: LCD display

Accessories

- Cables/Connection: MP3 Link cable
- Remote control
- User Manual: multi-lingual
- Others: Quick start guide
- Guaranteed: Worldwide Guarantee booklet

Dimensions

- Main speaker dimensions (W x D): 146 x 160 mm
- Gross weight: 7.7 kg
- Main speaker height: 232 mm
- Main unit depth: 287 mm
- Packaging depth: 350 mm
- Main unit height: 232 mm
- Packaging height: 275 mm
- Main unit width: 152 mm
- Packaging width: 378 mm

Power

- Power supply: 50 Hz
- Power supply: 220 - 240 V

Green

- Eco Power standby: 1 W



Issue date 2013-05-10

Version: 3.0.6

12 NC: 8670 000 50606
EAN: 87 12581 47066 1

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com