

PHILIPS

Over-ear wireless
headphones

Fidelio

Noise Cancellation Pro+
Natural, balanced sound
Leather premium design
38 hours play time



L3



Get inside the music. Anywhere.

What if you could always be in the perfect place to listen to the music you love? Exquisitely tuned drivers, excellent Active Noise Canceling, and the right fit combine to create the perfect listening environment. Wherever you are.

Detailed sound, no distractions

- Philips Fidelio. Engineered for exceptional performance
- 40 mm drivers. Natural, balanced sound
- State-of-the-art hybrid Active Noise Canceling

Quality in every detail

- Crafted for listening. Premium design
- Memory foam ear-cup cushions. Always a perfect fit
- Sumptuous Muirhead leather. Responsibly sourced
- Dual mics for crystal-clear calls. On-board voice control

Seamless in every way

- Touch controls. 38 hours play time (32 hours with ANC)*
- IR sensor. Music pauses when you take the headphones off
- Connect to any source. Wireless or wired
- Philips Headphones app. Customize your experience
- One-touch pairing. Google Fast Pair*

Highlights

Philips Fidelio



From the sound to the materials, these over-ear closed-back wireless headphones are crafted to bring you deep into the music. No matter what size or shape your head is, the soft memory-foam ear-cup cushions fit closely, and the music pauses if you take the headphones off.

Natural, balanced sound



The perfectly tuned drivers in these Hi-Res Audio certified headphones deliver beautifully balanced sound—whether ANC is turned on or off. Bass is tight and impactful without being overpowering. Midrange frequencies are full and smooth. High frequencies sparkle with detail.

Hybrid Active Noise Canceling



Listen at the perfect volume—wherever you are. Adaptive noise canceling uses one external mic and one internal mic to filter out

unwanted sounds, leaving you free to immerse. Awareness Mode lets you bring the world back in when you need to.

Crystal-clear calls



Two mics in each ear cup focus on the sound of your voice, dramatically reducing noise from the world around you. The fully integrated Google Assistant and Alexa are there to help you pull up your favorite playlists as soon as you ask.

Touch controls



A full charge gives you more than a day of music, and a speedy 15-minute charge gives you 6 hours play time. There are touch controls for music and calls, and buttons for ANC on the ear cups, which also fold flat for easy storage.

Crafted for listening



Lightweight aluminum and responsibly sourced Muirhead leather ensure these wireless headphones feel as premium as the

sound. The aluminum of the ear-cup rings is in matte dark satin, with embossed Philips Fidelio branding. The music pauses automatically when you take the headphones off.

Philips Headphones app.



The Philips Headphones app lets you adjust the level of noise cancellation by switching between preset ANC modes. It also features a dedicated equalizer, and you can use the app to control the music you're streaming or access song information.

Google Fast Pair*



Fast Pair

Google Fast Pair lets you pair your headphones to a compatible Android device with a single tap. When the headphones are placed near your Android device, you are automatically asked if you want to connect.



Specifications

Sound

Impedance: 16 Ohm
Speaker diameter: 40 mm
Sensitivity: 103 dB (1k Hz)
Frequency range: 7 - 40,000 Hz
Maximum power input: 20 mW
Hi-Res Audio
Driver type: Dynamic

ANC features

ANC (Active Noise Canceling)
ANC technology: Hybrid, ANC Pro+
Awareness mode
Adaptive ANC
Microphone for ANC: 4 mic

Telecommunication

Microphone for call: 2 mics
ENC microphone

Connectivity

Bluetooth version: 5.1
Supported codec: AAC, SBC, aptx, aptx-HD
Maximum range: Up to 10 m
Bluetooth profiles: A2DP, AVRCP, HFP
Detachable cable
Type of wireless transmission: Bluetooth
Multipoint connection
Wireless
Headphone socket: 2.5 mm

Convenience

Android fast pair
Auto pause (IR sensor)
Philips Headphones app support
Firmware updates possible
Automatic power off
Volume control
Type of controls: Touch

Design

Color: Black
Wearing style: Headband
Foldable design: Flat

Ear fitting: Over-ear
Earcup type: Closed-back
Ear coupling material: Synthetic leather

Power

Music play time (ANC on): 32 hr*
Music play time (ANC off): 38 hr*
Battery type(Headphones): Lithium Polymer (built-in)
Battery capacity(Headphones): 800 mAh
Talk time: 38 hr
Charging time: 2 hr
Fast charging time: 15 mins for 6 hrs
Number of batteries: 3 pcs
Battery weight (Total): 10.1 g
Rechargeable

Voice assistant

Voice assistant support
Voice assistant activation: Manual
Voice assistant compatible: Apple Siri, Google Assistant

Accessories

Audio cable: 2.5-3.5mm stereo cable, L=1.2m
Charging cable: USB-C cable, 500 mm
Included adapters: Airplane adapter
Others: 1 pcs hard carrying case
Quick Start Guide

Product dimensions

Product dimensions (W x H x D):
19 x 20.35 x 5.15 cm
Weight: 0.36 kg

Packaging dimensions

Packaging dimensions (W x H x D):
20.9 x 21.67 x 7.69 cm
EAN: 48 95229 10839 4
Number of products included: 1
Gross weight: 1.068 kg
Nett weight: 0.387 kg
Tare weight: 0.681 kg
Packaging type: Box
Type of shelf placement: Hanging

Outer Carton

Number of consumer packagings: 3
Outer carton (L x W x H): 25.4 x 22.8 x 26 cm
Gross weight: 3.655 kg
Tare weight: 2.494 kg
Nett weight: 1.161 kg
GTIN: 1 48 95229 10839 1

UPC

UPC: 8 40063 20164 4

