



Philips  
Portable Speaker System

SBD4000



## Powerful stereo sound stage

### Powerful XSL Acoustics

The slim mono-body of the SBD4000 portable speaker system slips easily into your pocket or bag. Share the powerful and realistic stereo sound stage with friends wherever you are, and experience amazing rich bass quality even at low volume.

#### Powerful Sound

- Dynamic Bass Boost electronically enhances the low tones
- Incredible Surround™ enhances the sound stage
- Built-in speakers featuring XSL Acoustics for dynamic sound

#### Take your music with you

- Carrying pouch to protect your speakers when not in use
- Universal use with all portable entertainment equipment
- Ultra slim mono body fit easily into pockets and bags

#### Always ready to go

- Cable neatly stored when not in use

# PHILIPS

# Specifications

## Sound

- Frequency response: 100 - 20 000 Hz
- Impedance: 3 ohm
- RMS Power rating: 2x3W (6W)
- Sensitivity: 80 dB
- Sound Enhancement: Dynamic Bass Boost, Incredible Surround
- Speaker diameter: 40 mm
- Type: Neodymium

## Connectivity

- Cable length: 0.3 m
- Connector: 3.5 mm stereo
- Finishing of connector: Nickel plated

## Convenience

- Bass level control
- Operating time: 6 hours
- Power on indication
- Volume control

## Accessories

- AC/DC Adaptor
- Pouch



## Power

- Adaptor type: 9V 500mA
- Battery type: AAA, LR03
- Battery voltage: 1.5 V
- Number of batteries: 6

## Packaging dimensions

- Packaging dimensions (W x H x D): 21.2 x 22.1 x 8.7 cm
- Gross weight: .713 kg
- Nett weight: .55 kg
- Tare weight: .163 kg

## Outer Carton

- Gross weight: 5.594 kg
- Outer carton (L x W x H): 54.9 x 23.5 x 22.9 cm
- Nett weight: 3.3 kg
- Tare weight: 2.294 kg

## Inner Carton

- Gross weight: 1.564 kg
- Inner carton (L x W x H): 22.4 x 17.8 x 20.6 cm
- Nett weight: 1.1 kg
- Tare weight: .464 kg

# Highlights

## DBB Dynamic Bass Boost

Activate the Dynamic Bass Boost (DBB), and the low-end bass frequencies are electronically enhanced to achieve consistent sound reproduction, especially when the speaker volume is set at a low level. You hear impressive bass at all times.

## Incredible Surround™

Incredible Surround™ widens the sound stage, giving you the impression of having extra speakers all around you.

## XSL Acoustics

Enjoy dynamic sound and powerful bass performance from your ShoqBox with XSL Acoustics. Impressive sound is produced by combining bright, brisk treble and mid range sound with elastic, powerful bass. Innovative use of high-tech materials like titanium cone and neodymium magnet deliver sound output that's nearly double the power of a traditional speaker driver of the same size. Precise tuning between the speaker driver, the small acoustic architecture and the circuitry ensures superbly dynamic sound and optimizes bass performance from the smallest sound enclosure.

## Carrying pouch

Look after your speaker and stop the cable getting tangled by storing it in this handy soft pouch when not in use.

## For portable equipment

Universal use with all portable entertainment equipment. Simply connect using the 3.5mm plug.

## Speaker cable management

With it's unique design, cable storage is no longer an issue. Simply pack and go.

## Ultra-compact and lightweight

Super slim and lightweight you'll hardly notice it's with you. Pop it in your pocket or bag and take it anywhere. Ultimate portability.



Issue date 2020-07-08

Version: 2.1.8

12 NC: 8670 000 26136  
EAN: 87 12581 30709 7

© 2020 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)