

Philips Soundbar speaker

3.1 CH wireless subwoofer Google Cast & Spotify Connect Bluetooth and NFC 1 HDMI in & HDMI out ARC



HTL5160B

# Unmatched voice clarity from 3.1 Ch

# with Google Cast & Spotify Connect

Upgrade your TV with enhanced voice clarity and virtual surround sound for better cinematic experience. Start enjoy high quality sound and seamless playback experience with your favorite music apps with this Google cast enabled soundbar.

# Connect and enjoy all your entertainment

- Easily send music from phone to speaker with Google Cast
- Spotify Connect for an effortless native app experience
- One-touch with NFC-enabled smartphones for Bluetooth paring
- Connect to one HDMI in for great picture and sound quality
- · EasyLink to control all HDMI CEC devices via a single remote

# Richer sound for watching TV and movies

- Dedicated center-channel speaker for superior voice clarity
- 2-way loudspeaker for the best clarity and dynamic range
- Dolby Digital and Pro Logic II surround sound
- Virtual Surround Sound for a realistic movie experience
- · Wireless subwoofer adds thrill to the action

### **Designed for simplicity**

- Philips companion app for easy network setup
- Low-rise profile for the perfect fit in front of your TV



3.1 CH wireless subwoofer Google Cast & Spotify Connect, Bluetooth and NFC, 1 HDMI in & HDMI out

# **Highlights**

## Center-channel speaker



A centre-channel speaker dedicated especially to voice frequencies anchor speech to the centre of the screen. This offers improved voice positioning and clarity, increasing immersion in movies.

# **One-touch with NFC**



Pair Bluetooth® devices easily with one-touch NFC (Near Field Communications) technology. Just tap the NFC enabled smartphone or tablet on the NFC area of a soundstage to turn the soundstage on, start Bluetooth® pairing, and begin streaming music.

# 2-way loudspeaker



2-way loudspeaker for the best clarity and explosive dynamic range

### **Google Cast**



Enjoy high quality and seamless playback with your favorite music apps. This soundbar has Google Cast built-in so you can cast your favorite music apps from your personal device to your speakers. You can cast from your iPhone®, iPad®, Android phone and tablet, Mac<sup>®</sup> and Windows<sup>®</sup> laptop, or Chromebook.

# Philips companion app



Use Philips HCWeSet Manager app to setup and connect your new speakers to your home wireless network and start enjoy the high quality audio and seamless playback experience from your favorite apps\*. \*It is mandatory to install the app for network setup, as well as services and privacy agreement before you can cast music wirelessly from your music apps. \*To cast music from Spotify, You'll need Spotify Premium to use Connect

### Spotify as a remote



Using Spotify Connect you can easily browse, explore, and play music from any room in the house using your smart device as a remote. With a direct Spotify connection, you can play music straight from the cloud so your smart device can be used for calls, videos or even go out of range without interrupting your music. This is also more battery friendly, since energy used for music is minimized. All the same great Spotify features are there, from its ready-made lists to its high sampling rates. Everything you need to discover new music and hear it at its best.



















### Soundbar speaker

3.1 CH wireless subwoofer Google Cast & Spotify Connect, Bluetooth and NFC, 1 HDMI in & HDMI out ARC

# Specifications

#### Sound

- Sound Enhancement: Night Mode, Treble and Bass Control, Virtual Surround Sound, Audio sync, Movie, Music, Voice, Auto Volume Leveler
- Sound System: Dolby Digital, Dolby pro-logic 2
- Speaker output power:  $40W \times 3$
- Subwoofer output power: 200W
- Total Power RMS @ 10% THD: 320 W

### Loudspeakers

- · Loudspeaker types: Integrated with main unit
- Subwoofer type: Wireless subwoofer
- Subwoofer driver: 1 x 8" woofer
- Subwoofer freq range: 45 200 Hz
- Subwoofer impedance: 2 ohm
- Drivers per Soundbar: 5 x race track woofers, 3 x tweeters

### **Connectivity**

- Integrated Connections: Bluetooth, NFC
- iPod/iPhone: via 3.5mm Audio In, via bluetooth
- Rear Connections: Digital optical in, HDMI 1.4 output (ARC), HDMI IN 1, Ethernet
- Top connections: Audio In (3.5mm), USB 2.0
- Online services: Google Cast  $^{\text{TM}}$  , Spotify Connect

### Convenience

 EasyLink (HDMI-CEC): Automatic audio input mapping, One touch standby, Remote Control-Passthrough, System standby, Audio Return Channel

# **Audio Playback**

Compression format: MP3

#### Design

• Wall mountable

### **Power**

- Main unit power supply: 100-240V AC, 50/60 Hz
- Main unit: Netwroked Standby power comsumption: <6W, ECO Standby power consumption: <0.5 W</li>
- Subwoofer Power supply: 100-240 V~; 50-60 Hz
- Subwoofer: Netwroked Standby power comsumption: <6W, ECO Standby power consumption: <0.5 W</li>
- Subwoofer power consumption: 30 W

### **Dimensions**

- Main Unit (W  $\times$  H  $\times$  D): 1100  $\times$  51  $\times$  69 mm
- Main Unit Weight: 2.2 kg
- Subwoofer (W x H x D): 205 x 316 x 401 mm
- Packaging (W x H x D): 475 x 355 x 373 mm
- Weight incl. Packaging: 12.2 kg
- Subwoofer Weight: 7 kg

### **Accessories**

 Included accessories: Quick start guide, Remote Control, Safety & Legal Leaflet, Trademarks Sheet, AC Adapter, 2 x Power cords, 2 x AAA Batteries, Screws (x6), Optical audio cable, User manual on CD-ROM

#### **Smartphone/Tablet App**

 App name: Philips HCWeSet, Free download from Apple App store and Google Play



Issue date 2020-07-08

© 2020 Koninklijke Philips N.V. All Rights reserved.

Version: 9.6.4

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 26473 EAN: 48 95185 61034 4

www.philips.com

\* Availability of music service depends on country. Please visit the relevant music service website for details.

\* Spotify premium account is required for this speaker.