

Philips
DVD player with USB

DivX

DVP3258



Enjoy USB 2.0 connectivity

and MP3 creation

Your dream player with flawless, true-to-life picture quality and the ability to play virtually any disc! The Philips DVD player delivers your movies and music entertainment experience.



Brings audio and video to life

- 12-bit/108 MHz video processing for sharp, natural images
- 192 kHz/24-bit audio DAC enhances analogue sound input
- High-quality outputs for analogue and digital audio
- Progressive Scan component video for optimised image quality
- 5.1 channel audio output for surround sound

Connect and enjoy multiple sources

- Hi-Speed USB 2.0 Link plays media from USB flash drives

Easy to use

- Create MP3s directly from CDs

Plays all your movies and music

- Plays DivX, MP3, WMA and JPEG digital camera photos
- Plays CD, (S) VCD, DVD, DVD+R/RW, DVD-R/RW
- DivX Certified for standard playback of DivX videos
- DivX with Chinese subtitles

PHILIPS

sense and simplicity

DVD player with USB
DivX

Specifications

Picture/Display

- **D/A converter:** 12-bit, 108 MHz
- **Picture enhancement:** Progressive Scan, Video upsampling

Sound

- **D/A converter:** 24-bit, 192 kHz
- **Frequency response:** 30-20,000 Hz
- **Signal to noise ratio:** > 90
- **Distortion and Noise (1 kHz):** > 65 dB
- **Crosstalk (1 kHz):** > 70 dB
- **Dynamic Range (1 kHz):** > 80 dB
- **Sound System:** Dolby Digital, DTS

Video Playback

- **Playback Media:** CD, CD-R/CD-RW, Video CD/SVCD, DVD, DivX, DVD+R/+RW, DVD-R/-RW, DVD-Video
- **Compression formats:** MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0
- **Video disc playback system:** PAL, NTSC

Audio Playback

- **Playback Media:** CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW, Audio CD
- **Compression format:** MP3, Dolby Digital, PCM, WMA
- **MP3 bit rates:** 32 - 320 kbps

Still Picture Playback

- **Playback Media:** DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD

- **Picture compression format:** JPEG
- **Picture enhancement:** Flip photos, Rotate, Zoom, Slideshow

Connectivity

- **Rear Connections:** Digital coaxial out, Composite video (CVBS) output, ComponentVideo out Progressive, Analogue audio multi-channel out

Convenience

- **Child Protection:** Child Lock, Parental Control
- **On-Screen Display languages:** English, Simplified Chinese

Power

- **Power supply:** 110-240V, 50/60 Hz
- **Power consumption:** < 10 W
- **Standby power consumption:** < 1 W

Accessories

- **Included Accessories:** Audio/Video cable, 2 x AAA Batteries, Remote Control, World Wide Warranty leaflet, User manual, Warranty Leaflet

Dimensions

- **Set dimensions (W x H x D):** 360 x 37 x 209 mm
- **Packaging dimensions (W x H x D):** 415 x 82 x 282 mm

Multimedia Applications

- **Multimedia connections:** USB memory class device
- **Playback Formats:** DivX, JPEG Still pictures, MP3

DVP3258/93

Product highlights

Plays it all

Play virtually any media format you want - whether it is DivX, MP3, WMA or JPEG. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theatre system - in the comfort of your living room.

192 kHz/24-bit audio DAC

192 kHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, it writes both fields at the same time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

5.1 channel audio output

Create MP3s

Convert the contents of your favourite CDs to MP3 files on your Philips product, and store it directly on a thumbdrive or on your portable media player through a USB cable. Enjoy the convenience of creating MP3 files right in your living room, without a PC, and even while the CD is playing.



Issue date 2009-02-16

Version: 1.0.7

12 NC: 8670 000 36283
EAN: 87 12581 38902 4

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com